Contact SAMSUNG WORLDWIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Country	Customer Care Centre ☎	Web Site
AUSTRALIA	1300 362 603	www.samsung.com/au
CHINA	800-810-5858 400-810-5858 010-6475 1880	www.samsung.com/cn
	HONG KONG:3698 - 4698	www.samsung.com/hk
INDIA	3030 8282 1-800-3000-8282 1800 110011	www.samsung.com/in
INDONESIA	0800-112-8888	www.samsung.com/id
JAPAN	0120-327-527	www.samsung.com/jp
MALAYSIA	1800-88-9999	www.samsung.com/my
NEW ZEALAND	0800 SAMSUNG (0800 726 786)	www.samsung.com/nz
PHILIPPINES	1-800-10-SAMSUNG(726-7864) 1-800-3-SAMSUNG(726-7864) 02-5805777	www.samsung.com/ph
SINGAPORE	1800-SAMSUNG(726-7864)	www.samsung.com/sg
THAILAND	1800-29-3232 02-689-3232	www.samsung.com/th
TAIWAN	0800-329-999	www.samsung.com/tw
VIETNAM	1 800 588 889	www.samsung.com/vn
SOUTH AFRICA	0860-SAMSUNG(726-7864)	www.samsung.com/za
U.A.E	800-SAMSUNG (726-7864) 8000-4726	www.samsung.com/ae

© 2010 Samsung Electronics Co., Ltd. All rights reserved.

BN68-02514B-00

LCD TV user manual

SAMSUNG

SERIES 6

LCD TV
user manual

imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service, please register your product at
www.samsung.com/hk

Model _____ Serial No. _____

Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

Still image warning

Avoid displaying still images (like jpeg picture files) or still image element (like TV programme logo, panorama or 4:3 image format, stock or news bar at screen bottom etc.) on the screen. Constant displaying of still picture can cause uneven wear of screen phosphor, which will affect image quality. To reduce risk of this effect, please follow below recommendations:

- Avoid displaying the same TV channel for long periods.
- Always try do display any image on full screen, use TV set picture format menu for best possible match.
- Reduce brightness and contrast values to minimum required to achieve desired picture quality, exceeded values may speed up the burnout process.
- Frequently use all TV features designed to reduce image retention and screen burnout, refer to proper user manual section for details.

Securing the Installation Space

Keep the required distances between the product and other objects (e.g. walls) to ensure proper ventilation.
Failing to do so may result in fire or a problem with the product due to an increase in the internal temperature of the product.

✎ When using a stand or wall-mount, use parts provided by Samsung Electronics only.

- If you use parts provided by another manufacturer, it may result in a problem with the product or an injury due to the product falling.

✎ The appearance may differ depending on the product.

Installation with a stand.	Installation with a wall-mount.





Contents

Getting Started 1

1 Accessories
2 Viewing the Control Panel
3 Viewing the Remote Control
5 Connecting to an Antenna
5 Plug & Play (Initial Setup)

Connections 6

6 Connecting to an AV Device
7 Connecting to an Audio Device
8 Changing the Input source

Basic Features 9

9 How to Navigate Menus
9 Using the **INFO** button (Now & Next guide)
9 Planning Your Viewing
11 Channel Menu
13 Picture Menu
15 Sound Menu
17 Setup Menu
20 Support Menu

Advanced Features 21

21 Connecting to a PC
22 Network Connection
24 Setting up the Network
26 Media Play
32 Anynet+
35 Internet@TV
37 AllShare
39 Calendar

Other Information 40

40 Installing the Wall Mount
41 Assembling the Cables
41 Anti-theft Kensington Lock
42 Securing the TV to the wall
43 Troubleshooting
46 Specifications

Check the Symbol!

TOOLS

This function can be used by pressing the **TOOLS** button on the remote control.

Note

One-touch Button

Getting Started

Accessories

✎ Please make sure the following items are included with your LCD TV. If any items are missing, contact your dealer.

✎ The items' colours and shapes may vary depending on the models.

- Remote Control & Batteries (AAA x 2)
- User Manual
- Warranty Card / Safety Guide (Not available in some locations)
- Cleaning Cloth
- Power Cord

- Blanking Bracket



- Cable tie

(46-55 inch TVs)

- Holder-Ring (4ea)

See separate guide for installing the stand.



- Stand (1EA)



- Guide Stand (1EA)

M4 X L12

- Screws (9EA)

Getting Started

Viewing the Control Panel

✎ The product colour and shape may vary depending on the model.



SOURCE	Toggles between all the available input sources. In the on-screen menu, use this button as you would use the ENTER button on the remote control.
MENU	Displays an on-screen menu, the OSD (on screen display), of your TV's features.
-VOL+	Adjusts the volume. In the OSD, use the -VOL+ buttons as you would use the ◄ and ► buttons on the remote control.
CH	Changes the channels. In the OSD, use the CH buttons as you would use the ▼ and ▲ buttons on the remote control.
Power Indicator	Blinks and turns off when the power is on and lights up in standby mode.
(Power)	Turns the TV on or off.
Remote control sensor	Aim the remote control towards this spot on the TV.

Standby mode

Do not leave your TV in standby mode for long periods of time (when you are away on a holiday, for example). A small amount of electric power is still consumed even when the power button is turned off. It is best to unplug the power cord.

Viewing the Remote Control

C630 Series Remote Control

✎ This is a special remote control for the visually impaired persons and has Braille points on the Power, Channel and Volume buttons.



Turns the TV on and off.

Selects the HDMI mode directly.

Change the channels directly.

TEXT function in MHEG.

Adjust the volume.

Display the main on-screen-menu.

View **Media Play**.

Quickly select frequently used functions.

Selects the on-screen menu items and changes the menu values.

Returns to the previous menu.

These buttons are for the **Channel Manager, Media Play** menu, etc.

Use these buttons in **Media Play** and **Anynet+** modes.
([●]: Controls recording for Samsung recorders that have the Anynet+ feature)

Displays and selects the available video sources.

Returns to the previous channel.

Cuts off the sound temporarily.

Changes channels.

Displays channel lists on the screen.

Displays the EPG (Electronic Programme Guide).

Displays information on the TV screen.

Exits the menu.

P.MODE: Press to select the picture mode.
S.MODE: Press to select the sound mode. (SRS TheaterSound).
DUAL: Sound effect selection.
AD: Turns the audio description on and off (not available in some locations).

P.SIZE: Selects the picture size.
SUBT.: Displays digital subtitles.

Getting Started

C650 Series Remote Control

✎ This is a special remote control for the visually impaired persons and has Braille points on the Power, Channel and Volume buttons.



Turns the TV on and off.

Displays and selects the available video sources.

Change the channels directly.

TEXT function in the MHEG.

Adjusts the volume.

Display the main on-screen-menu.

Displays the **Content View**, which includes **Guide, Internet@TV, Media Play**, and **AllShare**.

Quickly select frequently used functions.

Selects the on-screen menu items and changes the menu values.

Returns to the previous menu.

These buttons are for the **Channel Manager, Internet@TV, Media Play** menu, etc.

Use these buttons in **Media Play** and **Anynet+ (HDMI-CEC)** modes. (●: Controls recording for Samsung recorders that have the Anynet+ feature)

Turns the remote control light on or off. When on, the buttons become illuminated for a moment when pressed. (Using the remote control with this button set to off will reduce the battery usage time.)

Returns to the previous channel.

Cuts off the sound temporarily.

Changes channels.

Displays channel lists on the screen.

Displays the EPG (Electronic Programme Guide) .

Displays information on the TV screen.

Exits the menu.

MEDIA.P: Displays **Media Play**.
INTERNET: Link to various internet services.
DUAL: Sound effect selection.
AD: Turns the audio description on and off (not available in some locations).
P.SIZE: Selects the picture size.
SUBT.: Displays digital subtitles.

Installing batteries (Battery size: AAA)



✎ NOTE

- Use the remote control within 23 feet from the TV.
- Bright light may affect the performance of the remote control. Avoid using nearby special fluorescent light or neon signs.
- The colour and shape may vary depending on the model.

Connecting to an Antenna

When the TV is initially powered on, basic settings proceed automatically.

✎ Preset: Connecting the mains and antenna.



Plug & Play (Initial Setup)

When the TV is initially powered on, a sequence of on-screen prompts will assist in configuring basic settings. Press the POWER ⏻ button. **Plug & Play** is available only when the **Input** source is set to TV.

1	Selecting a language	Press the ▲ or ▼ button, then press the ENTER ↵ button. Select the desired OSD (On Screen Display) language.
2	Selecting **Store Demo** or **Home Use**	Press the ◄ or ► button, then press the ENTER ↵ button. • Select the **Home Use** mode. **Store Demo** Mode is for retail environments. • Return the unit's settings from **Store Demo** to **Home Use** (standard): Press the volume button on the TV. When the OSD volume is displayed, press and hold the MENU button on the TV for 5 sec.
3	Selecting an antenna	Press the ▲ or ▼ button, then press the ENTER ↵ button. Select **Air** or **Cable**.
4	Selecting a channel	Press the ▲ or ▼ button, then press the ENTER ↵ button. Select the channel source to memorise. When setting the antenna source to **Cable**, a step appears allowing you to assign numerical values (channel frequencies) to the channels. For more information, refer to **Channel → Auto Store**. ✎ Press the ENTER ↵ button at any time to interrupt the memorization process.
5	Setting the **Clock Mode**	Set the **Clock Mode** automatically or manually. Press the ▲ or ▼ button to select **Auto**, then press the ENTER ↵ button.
6	Viewing the **HD Connection Guide.**	The connection method for the best HD screen quality is displayed.
7	**Enjoy your TV.**	Press the ENTER ↵ button.

If You Want to Reset This Feature...

Select **Setup - Plug & Play** (Initial Setup). Enter your 4 digit PIN number. The default PIN number is "0-0-0-0." If you want to change the PIN number, use the **Change PIN** function.

Connections

Connecting to an AV Device

Using an HDMI / DVI Cable: HD connection (up to 1080p)

Available devices: DVD, Blu-ray player, HD cable box, HD STB (Set-Top-Box) satellite receiver, cable box, satellite receiver (STB)



✎ **HDMI IN 1(DVI), 2, 3, 4, PC/DVI AUDIO IN**

- When using an HDMI/DVI cable connection, you must use the **HDMI IN 1(DVI)** jack. For the DVI cable connection, use a DVI to HDMI cable or DVI-HDMI (DVI to HDMI) adapter for video connection and the **PC/DVI AUDIO IN** jacks for audio.
- If there is no sound after connecting an HDMI cable, check the HDMI version of the external device.

Using a Component (up to 1080p) or Audio/Video (480i only) Cable and Using a Scart Cable

Available devices: VCR, DVD, Blu-ray player, cable box, STB satellite receiver



✎ To obtain the best picture quality, the Component connection is recommended over the A/V connection.

Connecting to an Audio Device

Using an Optical (Digital) or Headphone Cable Connection

Available devices: digital audio system, amplifier, DVD home theatre



✎ DIGITAL AUDIO OUT (OPTICAL)

- When a digital audio system is connected to the **DIGITAL AUDIO OUT (OPTICAL)** jack, decrease the volume of both the TV and the system.
- 5.1 CH (channel) audio is available when the TV is connected to an external device supporting 5.1 CH.
- When the receiver (home theatre) is set to on, you can hear sound output from the TV's optical jack. When the TV is receiving a DTV signal, the TV will send 5.1 CH sound to the home theatre receiver. When the source is a digital component such as a DVD / Blu-ray player / cable box / STB (Set-Top-Box) satellite receiver and is connected to the TV via HDMI, only 2 CH audio will be heard from the home theatre receiver. If you want to hear 5.1 CH audio, connect the digital audio out jack from your DVD / Blu-ray player / cable box / STB satellite receiver directly to an amplifier or home theatre.

✎ Headphones 🎧: You can connect your headphones to the headphones output on your set. While the headphones are connected, the sound from the built-in speakers will be disabled.

- Sound function may be restricted when connecting headphones to the TV.
- Headphone volume and TV volume are adjusted separately.

Changing the Input Source

Source List

Use to select TV or other external input sources such as DVD / Blu-ray players / cable box / STB satellite receiver connected to the TV.

- **TV / PC / AV1/AV2/Component1 / Component2 / HDMI1/DVI / HDMI2 / HDMI3 / HDMI4 / USB**
  - ✎ In the **Source List**, connected inputs will be highlighted.
  - ✎ PC always stay actived

Edit Name

- **VCR / DVD / Cable STB / Satellite STB / PVR STB / AV Receiver / Game / Camcorder / PC / DVI PC / DVI Devices / TV / IPTV / Blu-ray / HD DVD / DMA**: Name the device connected to the input jacks to make your input source selection easier.
  - ✎ When a PC with a resolution of 1920 x 1080 @ 60Hz is connected to the **HDMI IN 1(DVI)** port, you should set the port **HDMI1/DVI to PC** under **Edit Name**.

Basic Features

How to Navigate Menus

Before using the TV, follow the steps below to learn how to navigate the menu and select and adjust different functions.



1. **ENTER** / Direction button: Move the cursor and select an item. Confirm the setting.
2. **RETURN** button: Returns to the previous menu.
3. **MENU** button: Displays the main on-screen menu.
4. **EXIT** button: Exits the on-screen menu.

How to Operate the OSD (On Screen Display)

The access step may differ depending on the selected menu.

1	MENU	The main menu options appear on the screen: **Picture, Sound, Channel, Setup, Input, Application, Support**.
2	▲ / ▼	Select an icon with the ▲ or ▼ button.
3	ENTER	Press **ENTER** to access the sub-menu.
4	▲ / ▼	Select the desired submenu with the ▲ or ▼ button.
5	◄ / ►	Adjust the value of an item with the ◄ or ► button. The adjustment in the OSD may differ depending on the selected menu.
6	ENTER	Press **ENTER** to complete the configuration.
7	EXIT	Press **EXIT**.

Using the INFO button (Now & Next guide)

The display identifies the current channel and the status of certain audio-video settings.

The Now & Next guide shows daily TV programme information for each channel according to the broadcasting time.

- Scroll ◄, ► to view information for a desired programme while watching the current channel.
- Scroll ▲, ▼ to view information for other channels. If you want to move to the currently selected channel, press the **ENTER** button.



Planning Your Viewing

Guide

The EPG (Electronic Programme Guide) information is provided by broadcasters. Using programme schedules provided by broadcasters, you can specify programmes you want to watch in advance so that the channel automatically changes to the selected programme channel at the specified time. Programme entries may appear blank or out of date depending on a channel status.

Using Channel View



Using Scheduled View



1. A Red (**View Mode**): View the list of programmes that are playing now or coming up.
2. C Yellow (**+24 hours**): Viewing the list of programmes to be broadcasted after 24 hours.
3. D Blue (**Ch. Mode**): Select the type of channels you want to display on the **Channel View** window. (**All, TV, Radio, Data/Other, My Channel 1~4**)
4. **Information**: Displays details of the selected programme.
5. **(Page):** Move to next or previous page.
6. ENTER button
   - When selecting the current programme, you can watch the selected programme.
   - When selecting the future programme, you can reserve to watch the selected programme. To cancel the schedule, press the ENTER button again and select **Cancel Schedules**.

Channel Manager

Add / delete or set favourites channels and use the programme guide for digital broadcasts. Select a channel in the **Channels, My Channels** or **Scheduled** screen.



- **Channels**: Shows the channel list according to channel type.
- **My Channels**: Shows the group of the channel.
- **Scheduled**: Shows all the currently reserved programmes.

Using the colour buttons with the **Channel Manager**

- A Red (**Antenna**): Toggle among **Air** or **Cable**.
- B Green (**Zoom**): Enlarges or shrinks a channel number.
- C Yellow (**Select**): Select desired channels and press the Yellow button to set all the selected channels at the same time. The ✓ mark appears to the left of the selected channels.
- D Blue (**Sort**): Change the list ordered by channel name or channel number.
- (**Page**): Move to next or previous page.
- (**Tools**): Displays the **Channel Manager** option menu. (The Options menus may differ depending on the situation.)

Channel Status Display Icons

Icons	Operations
A	An Analogue channel.
✓	A channel selected.
♥	A channel set as a Favourite.
	A programme currently being broadcast.
	A locked channel.
	A reserved programme.

Using Favourite Channels

♥ My Channels

(in **Channel Manager**)

Shows all favourite channels.

- **Edit My Channels** TOOLS : You can set the selected channels to desired my channels group.

✎ The "♥" symbol will be displayed and the channel will be set as a my channel.

1. Select a channel and press the **TOOLS** button.
2. Add or delete a channel in the my channel groups you want among 1, 2, 3 and 4.
   - One or more groups can be selected.
3. After you have changed the settings, the channel list for each group can be viewed in my channels.



Channel List

You can see all the channels searched.

Channel Menu

Retuning channels

Antenna

Your TV can memorize both Air and Cable channels.

- **Air**: Air antenna signal.
- **Cable**: Cable antenna signal.

Auto Store

Scans for a channel automatically and stores in the TV.

✎ Automatically allocated programme numbers may not correspond to actual or desired programme numbers. If a channel is locked using the **Child Lock** function, the PIN input window appears.

- **Antenna Source (Air / Cable / Auto)**: Select the antenna source to memorise.
- **Channel Source (Digital & Analogue / Digital / Analogue)**: Select the channel source to memorise.

Manual Store

Scans for a channel manually and stores in the TV.

✎ If a channel is locked using the **Child Lock** function, the PIN input window appears.

- **Digital Channel (Channel, Frequency, Bandwidth)**: (available in DTV mode) When scanning has finished, channels are updated in the channel list.
- **Analogue Channel (Programme, Colour System, Sound System, Channel, Search, Store)**: If there is abnormal sound or no sound, reselect the sound standard required.

✎ Channel mode

- **P** (programme mode): When tuning is complete, the broadcasting stations in your area have been assigned to position numbers from P0 to P99. You can select a channel by entering the position number in this mode.
- **C** (aerial channel mode) / **S** (cable channel mode): These two modes allow you to select a channel by entering the assigned number for each aerial broadcasting station or cable channel.

Editing channels

Channel Manager Option Menu

(in **Channel Manager**)

1. Select a channel and press the TOOLS button.
2. Edit the channel name or number using the **Edit Channel Name** or **Edit Channel Number** menu.

■ **Edit Channel Name (analogue channels only)**: Assign your own channel name.

■ **Edit Channel Number (digital channels only)**: Edit the number by pressing the number buttons desired.

Other Features

Cable Search Option

(depending on the country)

Sets additional search options such as the frequency and symbol rate for a cable network search.

■ **Freq.Start / Freq.Stop**: Set the start or stop frequency (differs in each country).

■ **Modulation**: Displays available modulation values.

■ **Symbol Rate**: Displays available symbol rates.

Channel Manager

Channel Manager Option Menu

(in **Channel Manager**)

Set each channel using the **Channel Manager** menu options (**Lock / Unlock, Timer Viewing, Sort , Select All / Deselect All**). Option menu items may differ depending on the channel status.

1. Select a channel and press the TOOLS button.
2. Select a function and change its settings.

■ **Lock / Unlock**: Lock a channel so that the channel cannot be selected and viewed.

✎ NOTE

- This function is available only when the **Child Lock** is set to **On**.
- The PIN input screen appears. Enter your 4-digit PIN, the default of which is “0-0-0-0”. Change the PIN using the **Change PIN** option.

■ **Timer Viewing**: You can set a desired channel to be displayed automatically at the intended time. Set the current time first to use this function.

✎ When a digital channel is selected, press the ► button to view the digital Programme.

■ **Sort** (analogue channels only): This operation allows you to change the programme numbers of the stored channels. This operation may be necessary after using the auto store.

■ **Delete**: You can delete a channel to display the channels you want.

■ **Select All / Deselect All**: Select all the channels or deselect all the selected channels in the channel manager.

Scheduled

(in **Channel Manager**)

You can view, modify or delete a show you have reserved to watch.

■ **Change Info**: Change a show you have reserved to watch.

■ **Cancel Schedules**: Cancel a show you have reserved to watch.

■ **Information**: Display a show you have reserved to watch. (You can also change the reservation information.)

■ **Select All**: Select all shows you have reserved to watch.

Fine Tune

(analogue channels only)

If the signal is weak or distorted, fine tune the channel manually.

Fine tuned channels are marked with an asterisk “*”.

LNA

If the TV is operating in a weak-signal area, the LNA function can improve the reception (a low-noise preamplifier boosts the incoming signal).

Picture Menu

Changing the Preset Picture Mode

Mode TOOLS

Select your preferred picture type.

- **Dynamic**: Suitable for a bright room.
- **Standard**: Suitable for a normal environment.
- **Natural**: Suitable for reducing eye strain.
  - ✎ **Natural** is not available in PC mode.
- **Movie**: Suitable for watching movies in a dark room.

Adjusting picture settings

Backlight / Contrast / Brightness / Sharpness / Colour / Tint (G/R)

Your television has several setting options for picture quality control.

✎ NOTE

- In analogue **TV, AV** modes of the PAL system, the **Tint (G/R)** function is not available.
- In PC mode, you can only make changes to **Backlight, Contrast** and **Brightness**.
- Settings can be adjusted and stored for each external device connected to the TV.
- Lowering picture brightness reduces power consumption.

Economical Solutions

Eco Solution

- **Energy Saving (Off / Low / Medium / High / Picture Off / Auto)** TOOLS : This adjusts the brightness of the TV in order to reduce power consumption. If you select **Picture Off**, the screen is turned off, but the sound remains on. Press any button(except Volume and power button) to turn on the screen again.
- **Eco Sensor (Off / On)**: To enhance your power savings; the picture settings will automatically adapt to the light in the room.

  Min Backlight: When **Eco sensor** is **On**, the minimum screen brightness can be adjusted manually.
- **No Signal Stand by (Off / 15 min / 30 min / 60 min)**: Activates the Stand-by mode, in the case of "No Signal" or "Check Signal Cable" status for a certain period of time defined by the user.
  - ✎ Disabled when the PC is in power saving mode.

Changing the Picture Options

Advanced Settings

(available in **Standard / Movie** mode)

You can adjust the detailed setting for the screen including colour and contrast.

✎ In PC mode, you can only make changes to **Dynamic Contrast, Gamma** and **White Balance**.



- **Black Tone (Off / Dark / Darker / Darkest)**: Select the black level to adjust the screen depth.
- **Dynamic Contrast (Off / Low / Medium / High)**: Adjust the screen contrast.
- **Shadow Detail (-2~+2)**: Increase the brightness of dark images.
  - ✎ Disabled under PC mode.
- **Gamma**: Adjust the primary colour intensity.
- **Expert Pattern (Off / Pattern1 / Pattern2)**: By running the **Expert Pattern** function, the picture can be calibrated without a generator or filter. If the OSD menu disappears or a menu other than the **Picture** menu is opened, the calibration is saved and the **Expert Pattern** window disappears.
  - ✎ While the **Expert Pattern** is running, sound is not outputted.
  - ✎ Only enabled on DTV / Component / HDMI.
- **RGB Only Mode (Off / Red / Green / Blue)**: You can adjust **Colour** or **Tint** of **Red, Green** or **Blue** for the picture from an external device (DVD player, home theatre, etc.).
- **Colour Space (Auto / Native / Custom)**: Adjust the range of colours available to create the image.
- **White Balance**: Adjust the colour temperature for a more natural picture.

  R-Offset / G-Offset / B-Offset: Adjust each colour's (red, green, blue) darkness.

  R-Gain/G-Gain/B-Gain: Adjust each colour's (red, green, blue) brightness.

  Reset: Resets the **White Balance** to it's default settings.

- **10p White Balance (Off / On)**: Controls the white balance in 10 point interval by adjusting the red, green, and blue brightness.
  - Available when the picture mode is set to **Movie** and when the external input is set to HDMI or Component.
  - Some external devices may not support this function.
- **Flesh Tone**: Emphasize pink “Flesh Tone.”
- **Edge Enhancement (Off / On)**: Emphasize object boundaries.
- **xvYCC (Off / On)**: Setting the **xvYCC** mode on increases detail and colour space when watching movies from an external device (e.g. DVD player) connected to the HDMI (YCbCr 4:4:4 and YCbCr 4:2:2) or Component IN jacks.
  - Available when the picture mode is set to **Movie** and when the external input is set to HDMI or Component.
  - Some external devices may not support this function.

Picture Options

In PC mode, you can only make changes to the **Colour Tone**, **Size** and **Auto Protection Time**.



- **Colour Tone (Cool / Normal / Warm1 / Warm2)**
  - **Warm1** or **Warm2** will be deactivated when the picture mode is **Dynamic**.
  - Settings can be adjusted and stored for each external device connected to an input on the TV.

- **Size**: Your cable box/satellite receiver may have its own set of screen sizes as well. However, we highly recommend you use 16:9 mode most of the time.

  Auto Wide: Automatically adjusts the picture size to the 16:9 aspect ratio.

  16:9 : Adjusts the picture size to 16:9 for DVDs or wide broadcasting.

  Wide Zoom: Magnifies the picture size more than 4:3.

  - Adjusts the Position by using ▲, ▼ buttons.

  Zoom: Magnifies the 16:9 wide pictures vertically to fit the screen size.

  - Adjusts the Position or Size by using ▲, ▼ button.

  4:3 : The default setting for a movie or normal broadcasting.

  - Do not watch in 4:3 format for a long time. Traces of borders displayed on the left, right and centre of the screen may cause image retention(screen burn) which are not covered by the warranty.

  Screen Fit: Displays the full image without any cut-off when HDMI (720p / 1080i / 1080p) or Component (1080i / 1080p) signals are inputted.

  NOTE

  - Depending on the input source, the picture size options may vary.
  - The available items may differ depending on the selected mode.
  - In PC mode, only **16:9** and **4:3** modes can be adjusted.
  - Settings can be adjusted and stored for each external device connected to an input on the TV.
  - After selecting **Screen Fit** in **HDMI** (1080i / 1080p) or **Component** (1080i / 1080p) mode: Adjusts the **Position** or **Size** by using ▲, ▼, ◄, ► button.
  - If you use the **Screen Fit** function with HDMI 720p input, 1 line will be cut at the top, bottom, left and right as in the overscan function.

- **Screen Mode (16:9 / Wide Zoom / Zoom / 4:3)**: Available only when picture size is set to **Auto Wide**. You can determine the desired picture size at the 4:3 WSS (Wide Screen Service) size or the original size. Each European country requires different picture size.
  - Not available in PC, Component or HDMI mode.

- **Digital Noise Filter (Off / Low / Medium / High / Auto / Auto Visualisation)**: When the broadcast signal is weak, some static and ghosting may appear. Select one of the options until the best picture is displayed.

  Auto Visualisation: When changing analogue channels, displays the intensity of the current signal and defines the screen NR.

  ✎ Only available for analogue channels.

- **MPEG Noise Filter (Off / Low / Medium / High / Auto)**: Reduces MPEG noise to provide an improved picture quality.

  ✎ Disabled under PC mode.

- **HDMI Black Level (Normal / Low)**: Selects the black level on the screen to adjust the screen depth.

  ✎ Available only in HDMI mode (RGB signals).

- **Film Mode (Off / Auto1 / Auto2)**: Sets the TV to automatically sense and process film signals from all sources and adjust the picture for optimum quality.

  ✎ Available in TV, AV, COMPONENT (480i / 1080i) and HDMI (480i / 1080i).

- **100Hz Motion Plus (Off / Clear / Standard / Smooth / Custom / Demo)** : Removes drag from fast scenes with a lot of movement to provide a clearer picture.

  ✎ If noise occurs on the screen, please set up the **100Hz Motion Plus** to **Off**. If **100Hz Motion Plus** is **Custom**, you can set up the **Blur Reduction, Judder Reduction** or **Reset** manually.

  ✎ If **100Hz Motion Plus** is **Demo**, you can compare the difference of on and off modes.

  Blur Reduction: Adjusts the blur reduction level from video sources.

  Judder Reduction: Adjusts the judder reduction level from video sources when playing films.

  Reset: Reset the custom settings.

- **Auto Protection Time (2 hours / 4 hours / 8 hours / 10 hours / Off)**: If the screen remains idle with a still image for a certain period of time defined by the user, the screen saver is activated to prevent the formation of ghost images on the screen.

Picture Reset (OK / Cancel)

Resets your current picture mode to its default settings.

Setting up the TV with Your PC

Set the input source to PC.

Auto Adjustment TOOLS

Adjust frequency values/positions and fine tune the settings automatically.

✎ Not available when connecting through HDMI/DVI cable.

Screen

- **Coarse / Fine**: Removes or reduces picture noise. If the noise is not removed by Fine-tuning alone, then adjust the frequency as best as possible (**Coarse**) and Fine-tune again. After the noise has been reduced, readjust the picture so that it is aligned to the centre of screen.
- **Position**: Adjust the PC screen position with direction button (▲ / ▼ / ◄ / ►).
- **Image Reset**: Resets the image to default settings.

Using Your TV as a Computer (PC) Display

Setting Up Your PC Software (Based on Windows XP)

Depending on the version of Windows and the video card, the actual screens on your PC may differ in which case the same basic set-up information will almost always be applied. (If not, contact your computer manufacturer or Samsung Dealer.)

1. Click on “Control Panel” on the Windows start menu.
2. Click on “Appearance and Themes” in the “Control Panel” window and a display dialog-box will appear.
3. Click on “Display” and a display dialog box will appear.
4. Navigate to the “Settings” tab on the display dialog-box.

- The correct size setting (resolution) [Optimum: 1920 X 1080 pixels]
- If a vertical-frequency option exists on your display settings dialog box, the correct value is “60” or “60 Hz”. Otherwise, just click “OK” and exit the dialog box.

Sound Menu

Changing the Preset Sound Mode

SRS TheaterSound TOOLS

- **Standard**: Selects the normal sound mode.
- **Music**: Emphasizes music over voices.
- **Movie**: Provides the best sound for movies.
- **Clear Voice**: Emphasizes voices over other sounds.
- **Amplify**: Increase the intensity of high-frequency sound to allow a better listening experience for the hearing impaired.

Adjusting sound settings

Equalizer

Adjusts the sound mode (standard sound mode only).

- Balance L/R: Adjusts the balance between the right and left speaker.
- **100Hz / 300Hz / 1KHz / 3KHz / 10KHz** (Bandwidth Adjustment): Adjusts the level of specific bandwidth frequencies.
- **Reset**: Resets the equalizer to its default settings.

Sound Systems, Etc.

SRS TruSurround HD (Off / On)

(standard sound mode only).

This function provides a virtual 5.1 channel surround sound experience through a pair of speakers or headphones using HRTF (Head Related Transfer Function) technology.

SRS TruDialog (Off / On)

(standard sound mode only).

This function allows you to increase the intensity of a voice over background music or sound effects so that dialog can be heard more clearly when viewing a show.

Audio Language

(digital channels only)

Change the default value for audio languages.

✎ The available language may differ depending on the broadcast.

Audio Format (MPEG / Dolby Digital 5.1)

(digital channels only)

When sound is emitted from both the main speaker and the audio receiver, a sound echo may occur due to the decoding speed difference between the main speaker and the audio receiver. In this case, use the TV Speaker function.

✎ **Audio Format** option may differ depending on the broadcast. 5.1ch Dolby digital sound is only available when connecting an external speaker through an optical cable.

Auto Volume (Off / Normal / Night)

To equalize the volume level on each channel, set to **Normal**.

- **Night**: This mode provides an improved sound experience compared to **Normal** mode, making almost no noise. It is useful at night.

Speaker Select (External Speaker / TV Speaker)

A sound echo may occur due to a difference in decoding speed between the main speaker and the audio receiver. In this case, set the TV to **External Speaker**.

✎ When **Speaker Select** is set to **External Speaker**, the volume and **MUTE** buttons will not operate and the sound settings will be limited.

✎ When **Speaker Select** is set to **External Speaker**, you should use these settings.

- **TV speaker: Off, External speaker: On**

✎ When **Speaker Select** is set to **TV Speaker**, you should use these settings.

- **TV speaker: On, External speaker: On**

✎ If there is no video signal, both speakers will be mute.

Additional Setting

(digital channels only)

- **DTV Audio Level (MPEG / HE-AAC)**: This function allows you to reduce the disparity of a voice signal (which is one of the signals received during a digital TV broadcast) to a desired level.

  ✎ According to the type of broadcast signal, **MPEG / HE-AAC** can be adjusted between -10dB and 0dB.

  ✎ To increase or decrease the volume, adjust between the range 0 and -10 respectively.

- **SPDIF Output**: SPDIF (Sony Philips Digital InterFace) is used to provide digital sound, reducing interference going to speakers and various digital devices such as a DVD player.

  Audio Format: During the reception of a digital TV broadcast, you can select the Digital Audio output (SPDIF) format from the options **PCM** or **Dolby Digital**.

  ✎ By connecting to 5.1ch speakers in a Dolby Digital setup, maximize your interactive 3D sound experience.

  Audio Delay: Correct audio-video mismatch, when watching TV or video, and listening to digital audio output using an external device such as an AV receiver.

- **Dolby Digital Comp (Line / RF)**: This function minimizes signal disparity between a dolby digital signal and a voice signal (i.e. MPEG Audio, HE-AAC, ATV Sound).

  ✎ Select **Line** to obtain dynamic sound, and **RF** to reduce the difference between loud and soft sounds at night time.

  Line: Set the output level for signals greater or less than -31dB (reference) to either -20dB or -31dB.

  RF: Set the output level for signals greater or less than -20dB (reference) to either -10dB or -20dB.

Sound Reset (OK / Cancel)

Reset all sound settings to the factory defaults.

Selecting the Sound Mode TOOLS

When you set to **Dual I II**, the current sound mode is displayed on the screen.

	Audio Type	Dual 1/2	Default
A2 Stereo	Mono	MONO	Automatic change
	Stereo	STEREO ↔ MONO	
	Dual	DUAL 1 ↔ DUAL 2	DUAL 1
NICAM Stereo	Mono	MONO	Automatic change
	Stereo	MONO ↔ STEREO	
	Dual	MONO ↔ DUAL 1 DUAL 2	DUAL 1

✎ If the stereo signal is weak and an automatic switching, occurs, then switch to the mono.

✎ Only activated in stereo sound signal.

✎ Only available when the **Input** source is set to **TV**.

Setup Menu

Setting the Time

Time

- **Clock**: Setting the clock is for using various timer features of the TV.

  The current time will appear every time you press the **INFO** button.

  ✎ If you disconnect the power cord, you have to set the clock again.

  Clock Mode (Auto / Manual)

  ✎ Depending on the broadcast station and signal, the auto time set up may not be correct. In this case, set the time manually.

  ✎ The antenna must be connected in order to set the time automatically.

  Clock Set: Set the **Day, Month, Year, Hour** and **Minute** manually.

  ✎ Available only when **Clock Mode** is set to **Manual**.

Using the Sleep Timer

- **Sleep Timer** TOOLS : Automatically shuts off the TV after a preset period of time. (30, 60, 90, 120, 150 and 180 minutes).

  ✎ To cancel **Sleep Timer**, select **Off**.

Setting the On/Off Timer

- **Timer 1 / Timer 2 / Timer 3**: Three different on / off timer settings can be made. You must set the clock first.



On Time / Off Time: Set the hour, minute, and activate / inactivate. (To activate timer with the setting you've chosen, set to **Activate**.)

Volume: Set the desired volume level.

Source: Select **TV** or **USB** content to be played when the TV is turned on automatically. (**USB** can be selected only when a USB device is connected to the TV)

Antenna (when the **Source** is set to **TV**): Select a proper antenna source you want.

Channel (when the **Source** is set to **TV**): Select the desired channel.

Contents (when the **Source** is set to **USB**): Select a folder in the USB device containing music or photo files to be played when the TV is turned on automatically.

✎ If there is no music file on the USB device or the folder containing a music file is not selected, the Timer function does not operate correctly.

✎ When there is only one photo file in the USB device, the Slide Show will not play.

✎ If a folder name is too long, the folder cannot be selected.

✎ Each USB you use is assigned its own folder. When using more than one of the same type of USB, make sure the folders assigned to each USB have different names.

Repeat: Select **Once, Everyday, Mon~Fri, Mon~Sat, Sat~Sun** or **Manual** to set at you convenience. If you select **Manual**, you can set up the day you want to activate the timer.

✎ The ✓ mark indicates the day is selected.

✎ Auto Power Off (available only when the TV is turned on by Timer): The TV will be automatically turned off after 3 hours of being left idle to prevent overheating.

Locking Programs

Security

✎ The PIN input screen appears before the setup screen.

✎ Enter your 4-digit PIN, the default of which is "0-0-0-0". Change the PIN using the **Change PIN** option.

- **Child Lock (Off / On)**: Lock channels in **Channel Manager**, to prevent unauthorized users, such as children, from watching unsuitable programme.

  ✎ Available only when the **Input** source is set to **TV**.

- **Change PIN**: Change your personal ID number required to set up the TV.

  ✎ If you forget the PIN code, press the remote control buttons in the following sequence, which resets the PIN to "0-0-0-0": **POWER** (off) → **MUTE** → 8 → 2 → 4 → **POWER** (on).

Other Features

Language

- **Menu Language**: Set the menu language.
- **Preference (Primary Audio Language / Secondary Audio Language / Primary Subtitle Language / Secondary Subtitle Language)**: Select a language, which will be the default language when a channel is selected.

Subtitle

Use this menu to set the **Subtitle** mode.

- **Subtitle (Off / On)**: Switches subtitles on or off.
- **Mode (Normal / Hearing Impaired)**: Sets the subtitle mode.
- **Subtitle Language**: Sets the subtitle language.

  ✎ If the programme you are watching does not support the **Hearing Impaired** function, **Normal** automatically activates even if the **Hearing Impaired** mode is selected.

  ✎ English is the default in cases where the selected language is unavailable in the broadcast.

- **Digital Text**: If the broadcasts with digital text, this feature is enabled.

  ✎ Some external deviced may not support this function.

Network (Network Type / Network Setup / Network Test)

For details on setting up options, refer to the "Setting up the Network" instructions.

General

- **Game Mode (Off / On)**: When connecting to a game console such as PlayStation™ or Xbox™, you can enjoy a more realistic gaming experience by selecting game mode.

✎ NOTE

- Precautions and limitations for game mode
  - To disconnect the game console and connect another external device, set **Game Mode** to **Off** in the setup menu.
  - If you display the TV menu in **Game Mode**, the screen shakes slightly.
- **Game Mode** is not available in TV and PC mode.
- After connecting the game console, set **Game Mode** to **On** to prevent poor picture quality.
- If **Game Mode** is **On**: **Picture** mode is set to **Standard** and **Sound** mode is set to **Movie**.
- Selecting Reset after adjusting the equalizer returns the equalizer to its default settings.

- **BD Wise (Off / On)**: Provides the optimal picture quality for Samsung DVD, Blu-ray and Home Theatre products which support **BD Wise**. When **BD Wise** is turned **On**, the picture mode is automatically changed to the optimal resolution.

  ✎ Available when connecting Samsung products that support **BD Wise** through a HDMI cable.

- **Menu Transparency (Bright / Dark)**: Se t the Transparency of the menu.
- **Melody (Off / Low / Medium / High)**: Set so that a melody plays when the TV is turned on or off.

Picture In Picture (PIP)

PIP TOOLS

Watches simultaneously the TV tuner and one external video source. **PIP** (Picture-in-Picture) does not function in the same mode.

✎ NOTE

- For PIP sound, refer to the **Sound Select** instructions.
- If you turn the TV off while watching in **PIP** mode, the PIP window will disappear.
- You may notice that the picture in the PIP window becomes slightly unnatural when you use the main screen to view a game or karaoke.
- While **Internet@TV** is in operation, the **PIP** function cannot be used.
- PIP settings

Main picture	Sub picture
Component1/2, HDMI1/ DVI, HDMI2, HDMI3, HDMI4, PC	TV

- **PIP (Off / On)**: Activate or deactivate the PIP function.
- **Air/Cable**: Select the antenna.
- **Channel**: Select the channel for the sub-screen.
- **Size (▭ / ▭)**: Select a size for the sub-picture.
- **Position (▭ / ▭ / ▭ / ▭)**: Select a position for the sub-picture.
- **Sound Select (Main / Sub)**: You can choose the desired sound (**Main / Sub**) in **PIP** mode.

  ✎ Available when **PIP** is set to **On**.

Support Menu

Self Diagnosis

- **Picture Test (Yes / No)**: Use to check for picture problems and if the problem continues to occur check the colour pattern.
- **Sound Test (Yes / No)**: Use the built-in melody sound to check for sound problems.
  - ✎ If you hear no sound from the TV's speakers, before performing the sound test, make sure **Speaker Select** is set to **TV speaker** in the **Sound** menu.
  - ✎ The melody will be heard during the test even if **Speaker Select** is set to **External Speaker** or the sound is muted by pressing the **MUTE** button.
- **Signal Information**: (digital channels only) HDTV channel's reception quality is either perfect or the channels are unavailable. Adjust your antenna to increase signal strength.
- **Troubleshooting**: If the TV seems to have a problem, refer to this description.
  - ✎ If none of these trouble shooting tips apply, contact the Samsung customer service centre.

Software Upgrade

Software Upgrade can be performed via a broadcasting signal or by downloading the latest software from samsung.com to a USB memory device.

Current Version the software already installed in the TV.

✎ Software is represented as "Year/Month/Day_Version".

Installing the Latsted Version

- **By USB**: Insert a USB drive containing the software upgrade file, downloaded from "www.samsung.com," into the TV. Please be careful not to disconnect the power or remove the USB drive until upgrades are complete. The TV will be turned off and on automatically after completing the software upgrade. When software is upgraded, video and audio settings you have made will return to their default settings. We advise you to to write down your settings so that you can easily reset them after the upgrade.



- **By Online**: Upgrade the software using the Internet.
  - ✎ First, configure your network. For detailed procedures on using the Network Setup, refer to the "Setting up the Network" instructions.
  - ✎ If the internet connection doesn't operate properly, the connection may be broken. Please retry downloading. If the problem persists, download by USB and upgrade.
- **By Channel**: Upgrade the software using the broadcasting signal.
  - ✎ If the function is selected during the software transmission period, software will be automatically searched and downloaded.
  - ✎ The time required to download the software is determined by the signal status.
- **Standby Mode Upgrade**: A manual upgrade will be automatically performed at selected time. Since the power of the unit is turned on internally, the screen may be turned on slightly for the LCD product. This phenomenon may continue for more than 1 hour until the software upgrade is complete.
- **Alternative Software**: Display the software version downloaded through By Online. During the software upgrading, when the upgrade will discontinue from the last step, this function be activated.

HD Connection Guide

Refer to this information when connecting external devices to the TV.

Contact Samsung

View this information when your TV does not work properly or when you want to upgrade the software. You can find information regarding our call centres, and how to download products and software.

Connecting to a PC

Using an HDMI/DVI Cable / a D-sub Cable



Display Modes (D-Sub and HDMI/DVI Input)

Optimal resolution is 1920 X 1080 @ 60 Hz.

Mode	Resolution	Horizontal Frequency (KHz)	Vertical Frequency (Hz)	Pixel Clock Frequency (MHz)	Sync Polarity (H / V)
IBM	640 x 350	31.469	70.086	25.175	+/-
	720 x 400	31.469	70.087	28.322	-/+
MAC	640 x 480	35.000	66.667	30.240	-/-
	832 x 624	49.726	74.551	57.284	-/-
	1152 x 870	68.681	75.062	100.000	-/-
VESA CVT	720 x 576	35.910	59.950	32.750	-/+
	1152 x 864	53.783	59.959	81.750	-/+
	1280 x 720	56.456	74.777	95.750	-/+
	1280 x 960	75.231	74.857	130.000	-/+
VESA DMT	640 x 480	31.469	59.940	25.175	-/-
	640 x 480	37.861	72.809	31.500	-/-
	640 x 480	37.500	75.000	31.500	-/-
	800 x 600	37.879	60.317	40.000	+/+
	800 x 600	48.077	72.188	50.000	+/+
	800 x 600	46.875	75.000	49.500	+/+
	1024 x 768	48.363	60.004	65.000	-/-
	1024 x 768	56.476	70.069	75.000	-/-
	1024 x 768	60.023	75.029	78.750	+/+
	1152 x 864	67.500	75.000	108.000	+/+
	1280 x 1024	63.981	60.020	108.000	+/+
	1280 x 1024	79.976	75.025	135.000	+/+
	1280 x 720	45.000	60.000	74.250	+/+
	1280 x 800	49.702	59.810	83.500	-/+
	1280 x 800	62.795	74.934	106.500	-/+
	1280 x 960	60.000	60.000	108.000	+/+
	1360 x 768	47.712	60.015	85.500	+/+
	1440 x 900	55.935	59.887	106.500	-/+
	1440 x 900	70.635	74.984	136.750	-/+
	1680 x 1050	65.290	59.954	146.250	-/+
VESA GTF	1280 x 720	52.500	70.000	89.040	-/+
	1280 x 1024	74.620	70.000	128.943	-/-
VESA DMT / DTV CEA	1920 x 1080p	67.500	60.000	148.500	+/+

✎ NOTE

- For HDMI/DVI cable connection, you must use the **HDMI IN 1(DVI)** jack.
- The interlace mode is not supported.
- The set might operate abnormally if a non-standard video format is selected.
- Separate and Composite modes are supported. SOG(Sync On Green) is not supported.

Network Connection

You can set up your TV so that it can access the Internet through your local area network (LAN) using a wired or wireless connection.

Connecting to a Wired Network

You can attach your TV to your LAN using cable in three ways:

- You can attach your TV to your LAN by connecting the LAN port on the back of your TV to an external modem using a Cat 5 cable. See the diagram below.



- You can attach your TV to your LAN by connecting the LAN port on the back of your TV to a IP Sharer which is connected to an external modem. Use Cat 5 cable for the connection. See the diagram below.



- Depending on how your network is configured, you may be able to attach your TV to your LAN by connecting the LAN port on the back of your TV directly to a network wall outlet using a Cat 5 cable. See the diagram below. Note that the wall outlet is attached to a modem or router elsewhere in your house.



If you have a Dynamic Network, you should use an ADSL modem or router that supports Dynamic Host Configuration Protocol (DHCP). Modems and routers that support DHCP automatically provide the IP address, subnet mask, gateway, and DNS values your TV needs to access the Internet so you don't have to enter them manually. Most home networks are Dynamic Networks.

Some networks require a Static IP address. If your network requires a Static IP address, you must enter the IP address, subnet mask, gateway, and DNS values manually on your TV's Cable Setup Screen when you set up the network connection. To get the IP address, subnet mask, gateway, and DNS values, contact your Internet Service Provider (ISP). If you have a Windows computer, you can also get these values through your computer.

✎ You can use ADSL modems that support DHCP if your network requires a Static IP address. ADSL modems that support DHCP also let you use Static IP addresses.

Network Connection - Wireless

Connect to the network wirelessly through a wireless IP sharer.

1. Connect the “Samsung Wireless LAN Adapter” into the **USB 1 (HDD) or USB 2** terminal of the TV.

✎ To use the **SWL(Samsung Wireless Link)** function, connect to the **USB 1 (HDD)** port.



✎ **NOTE**

- You must use the “Samsung Wireless LAN Adapter” (WIS09ABGN) to use a wireless network.
- Samsung’s Wireless LAN adapter is sold separately. The WIS09ABGN Wireless LAN adapter is offered by select retailers, Ecommerce sites and Samsungparts.com.
- To use a wireless network, your TV must be connected to a wireless IP sharer. If the wireless IP sharer supports DHCP, your TV can use a DHCP or static IP address to connect to the wireless network.
- Samsung’s Wireless LAN adapter supports IEEE 802.11A, IEEE 802.11B, IEEE 802.11G, IEEE 802.11N. When you play DLNA video over IEEE 802.11B/G connection, the video may not be played smoothly.
- Select a channel for the wireless IP sharer that is not currently being used. If the channel set for the wireless IP sharer is currently being used by another device nearby, this will result in interference and communication failure.
- If you apply a security system other than the systems listed blow, it will not work with the TV.
- When applying the security key for the AP (Access Point), only the following is supported.
  1) Authentication Mode : OPEN, SHARED, WPAPSK, WPA2PSK
  2) Encryption Type : WEP, TKIP, AES
  When applying the security key for the Ad-hoc mode, only the following is supported.
  1) Authentication Mode : SHARED, WPANONE
  2) Encryption Type : WEP, TKIP, AES
- If your AP supports WPS (Wi-Fi Protected Setup), you can connect to the network via PBC (Push Button Configuration) or PIN (Personal Identification Number). WPS will automatically configure the SSID and WPA key in either mode.
- If the device isn’t certified, it may not connect to the TV via the “Samsung Wireless LAN Adapter”.

Setting up the Network

Network Type (Wired / Wireless)

Select **Wired** or **Wireless** to connect to the network.

✎ **Wireless** is activated only if the “Samsung Wireless LAN Adapter” is connected.

Network Setup

■ **Wired Network Setup**: (when **Network Type** is set to **Wired**)

✎ Please check if the LAN cable is connected.



Wired Network Setup (Auto / Manual)

If you connect the LAN cable and it supports DHCP, you can set **Internet Protocol Setup** to **Auto**. If the LAN supports a static IP address, you must set **Internet Protocol Setup** to **Manual**.

1. Set **Network Type** to **Wired**.
2. Select **Network Setup**.
   - Set **Internet Protocol Setup** and **DNS Server** to **Auto** or **Manual**. If you set to **Manual**, you can set up **IP Address, Subnet Mask, Gateway** and **DNS Server** manually by pressing number buttons on the remote control.
3. Select **Network Test** to check the network connectivity.

■ **Wireless Network Setup**

✎ The menu is activated only if the “Samsung Wireless LAN Adapter” is connected.

Select a network

– **Access Point**: You can select the IP sharer to use when using a wireless network.

✎ **NOTE**

- If a wireless Access Point is not in the Access Point list, press the Red button.
- When the connection is made, you will be returned to the screen automatically.
- If you have selected an Access Point with a security authentication: The Security Key input screen appears. Enter the security key and press the Blue button on the remote control.
- If security encryption type is WEP, 0~9 and A~F will be available when you input security key.

Connecting WPS (Wi-Fi Protected Setup)

– If **Security Key** is already set: In access point list, select WPS.

✎ You can select **PBC, PIN, Security Key**.

Connecting by using **PBC**: Select a PBC (Push Button Configuration). Press the PBC button on the AP (Access Point) within 2minutes, and wait for connection.

Connecting by using **PIN**: Select a PIN (Personal Identification Number).

✎ The message showing the PIN Code is displayed. Input the PIN Code at AP device within 2minutes. Select OK and wait for connection.

✎ Try again if connecting operation doesn’t work.

✎ When the connection is not established although tried again, reset the access point. Please refer to a manual of each access point.

Connecting by using **Security Key**: When selecting **Security Key**, the input window is displayed. Input the security key and press the Blue button.

✎ Try again if connecting operation doesn’t work.

– If **Security Key** is not set: When the security setting of AP that supports WPS is NONE, you can select **PBC, PIN, None Security**. **None Security** is capable of connecting to AP directly without using the WPS function.

✎ Process for PBC, PIN is same as above. Refer to “If Security Key is already set.”

✎ Try again if connecting operation doesn’t work.

Ad-hoc: You can connect to a mobile device without an access point through the “Samsung Wireless LAN Adapter” by using a peer to peer network.

How to connect to new **Ad-hoc**

1. Choose **Select a network**.
2. While in the device list, press the Blue button on the remote or select **Ad-hoc**.

✎ The message **The existing network system may have limited functionality. Do you want to change the network connection?** is displayed.

3. Input the generated **Network Name (SSID)** and **Security Key** into the device you want to connect.

How to connect an existing Ad-hoc device

1. Choose **Select a network**. Then, the device list will be displayed.
2. Select the device you want in the Device list.
3. If security key was applied, input the security key again.

✎ If network doesn’t operate normally, check the **Network Name (SSID)** and **Security Key** again. An incorrect **Security Key** may cause a malfunction.

Wireless Network Setup (Auto / Manual)

If you connect the AP which supports DHCP, you can set **Internet Protocol Setup** to **Auto**.

If The AP supports a static IP address, you must set **Internet Protocol Setup** to **Manual**.

1. Set **Network Type** to **Wireless**.
2. Select **Network Setup**.
   - Selects an AP(Access Point) and ad hoc network.
   - Set **Internet Protocol Setup** and **DNS Server** to **Auto** or **Manual**. If you set to **Manual**, you can set up **IP Address, Subnet Mask, Gateway** and **DNS Server** manually by pressing number buttons on the remote control.
3. Select **Network Test** to check the network connectivity.

Network Test

Test or confirm the network connection status after setting up the network.

✎ When unable to **connect to a wired network**

- If your internet service provider has already registered the **MAC address** of the PC you're using to connect to the internet and authenticates the address each time you connect to the internet, your TV may not connect to the internet because the MAC address differs from that of the PC. In this case, ask your Internet service provider about the procedures to **connect devices other than your PC** (such as your TV) to the Internet.
- If your Internet service provider requires an **ID** or **password** to connect to the Internet (network), your TV may not be able to connect to the Internet. In this case, you have to enter your ID or password when connecting to the Internet using an Internet sharer (router).
- The internet connection may fail due to a **firewall** problem. In this case, contact your Internet service provider. If you cannot connect to the Internet even if you have followed the procedures of your Internet service provider, please contact Samsung Electronics.

✎ When unable to connect to an **AP** (Access Point)

- Your TV may fail to locate an AP (Access Point) that is configured as a private SSID type. In this case, please change the AP settings and try again. If your internet service provider has already registered the **MAC address** of the PC you're using to connect to the internet and authenticates the address each time you connect to the internet, your TV may not connect to the internet because the MAC address differs from that of the PC. In this case, ask your Internet service provider about the procedures to **connect devices other than your PC** (such as your TV) to the Internet. If you cannot connect to the Internet even if you have followed the procedures of your Internet service provider, please contact Samsung Electronics.

Advanced Features

Media Play

Enjoy photos, music and movie files saved on a USB Mass Storage Class (MSC) device or your PC.

Connecting a USB Device

1. Turn on your TV.
2. Connect a USB device containing photo, music and movie files to the **USB 1 (HDD)** or **USB 2** jack on the side of the TV.
3. When USB is connected to the TV, popup window appears. Then you can select **Media Play**.



Connecting to the PC through network

You can play pictures, music and videos saved on your PC through a network connection in the **Media Play** mode.

✎ If you use Media Play through saved file on your PC, you should download “PC Share Manager” and users manual from “www.samsung.com”.



1. For more information on how to configure your network, refer to “Network Connection”.
   – You are recommended to locate both TV and PC in same subnet. The first 3 parts of the subnet address of the TV and the PC IP addresses should be the same and only the last part (the host address) should be changed. (e.g. IP Address: 123.456.789.**)
2. Using a LAN cable, connect between the external modem and the PC onto which the Samsung PC Share Manager program will be installed.
   – You can connect the TV to the PC directly without connecting it through a Sharer (Router).

✎ No supported functions when connecting to the PC through network:

- The **Background Music** and **Background Music Setting** functions.
- Sorting files by preference in the **Photos**, **Music**, and **Videos** folders.
- The ◀◀ (REW) or ▶▶ (FF) button while a movie is playing.

✎ The Divx DRM, Multi-audio, embedded caption does not supported.

✎ Samsung PC Share manager should be permitted by the firewall program on your PC.

✎ When you use **Media Play** mode through a network connection, According to functions of the provided server:

- The sorting method may vary.
- The scene search function may not be supported.
- The **Play Continuously** function, which resumes playing of a video, may not be supported.
  - The **Play Continuously** function does not support multiple users. (It will have only memorised the point where the most recent user stopped playing.)
- The ◀◀ (REW), ▶▶ (FF) or ⏸ (Pause) button may not work depending on the content information.
- If you experience any file stuttering issue while playing a video over a wireless network, we recommend using a wired network.

✎ It might not work properly with unlicenced multimedia files.

✎ Need-to-Know List before using **Media Play**

- MTP (Media Transfer Protocol) is not supported.
- The file system supports FAT16, FAT32 and NTFS.
- Certain types of USB Digital camera and audio devices may not be compatible with this TV.
- Media Play only supports USB Mass Storage Class (MSC) devices. MSC is a Mass Storage Class Bulk-Only Transport device. Examples of MSC are Thumb drives, Flash Card Readers and USB HDD (USB HUB are not supported). Devices should be connected directly to the TV's USB port.
- Before connecting your device to the TV, please back up your files to prevent them from damage or loss of data. SAMSUNG is not responsible for any data file damage or data loss.
- Connect a USB HDD to the dedicated port, **USB 1 (HDD)** port.
- Do not disconnect the USB device while it is loading.
- The higher the resolution of the image, the longer it takes to display on the screen.
- The maximum supported JPEG resolution is 15360X8640 pixels.
- For unsupported or corrupted files, the "Not Supported File Format" message is displayed.
- If the files are sorted by Basic View, up to 1000 files can be displayed in each folder.
- MP3 files with DRM that have been downloaded from a non-free site cannot be played. Digital Rights Management (DRM) is a technology that supports the creation of content, the distribution and management of the content in an integrated and comprehensive way, including the protection of the rights and interests of the content providers, the prevention of the illegal copying of contents, as well as managing billings and settlements.
- If more than 2 PTP devices are connected, you can only use one at a time.
- If more than two MSC devices are connected, some of them may not be recognized. A USB device that requires high power (more than 500mA or 5V) may not be supported.
- If an over-power warning message is displayed while you are connecting or using a USB device, the device may not be recognized or may malfunction.
- If the TV has been no input during time set in **Auto Protection Time**, the Screensaver will run.
- The power-saving mode of some external hard disk drives may be released automatically when connected to the TV.
- If a USB extension cable is used, the USB device may not be recognized or the files on the device may not be read.
- If a USB device connected to the TV is not recognized, the list of files on the device is corrupted or a file in the list is not played, connect the USB device to the PC, format the device and check the connection.
- If a file deleted from the PC is still found when Media Play is run, use the "Empty the Recycle Bin" function on the PC to permanently delete the file.

Advanced Features

Screen Display

Move to the file you desired using the up/down/right/left buttons and then press the **ENTER** button. The file is played.



Information :
You can ascertain the selected file name and the number of files and page.

Sort List Section :
Displays sorting standard.

✎ Sorting standard is different depending on the contents.

File List Section :
You can confirm the files and groups that is sorted by each category.

Operation Button
A Red button : Selects a connected device.
B Green button : Sets the file preference. (not supported in Basic view)
C Yellow button : Selects multiple files from file list. Selected files are marked with a symbol.
D Blue button : Select the sort list
Tools button : Displays the option menu.

✎ Using the ◄◄ or ►► button, file list can move to next or previous page.

Videos

Playing a Video

1. Press the ◄ or ► button to select **Videos**, then press the **ENTER** button in the **Media Play** menu.
2. Press the ◄/►/▲/▼ button to select the desired video in the file list.
3. Press the **ENTER** button or ► (Play) button.
   - The selected file is displayed on the top with its playing time.
   - If video time information is unknown, play time and progress bar are not displayed.
   - During playing the vedio, you can search using the ◄ and ► button.

✎ In this mode, you can enjoy movie clips contained on a Game, but you cannot play the Game itself.

- Supported Subtitle Formats

Name	File extension	Format
MPEG-4 time-based text	.ttxt	XML
SAMI	.smi	HTML
SubRip	.srt	string-based
SubViewer	.sub	string-based
Micro DVD	.sub or .txt	string-based

- Supported Video Formats

File Extention	Container	Video Codec	Resolution	Frame rate (fps)	Bit rate (Mbsp)	Audio Codec
*.avi *.mkv	AVI MKV	Divx 3.11 / 4.x / 5.1 / 6.0	1920x1080	6 ~ 30	8	MP3 / AC3 / LPCM / ADPCM / DTS Core
		XviD	1920x1080	6 ~ 30	8	
		H.264 BP / MP / HP	1920x1080	6 ~ 30	25	
		MPEG4 SP / ASP	1920x1080	6 ~ 30	8	
		Motion JPEG	800x600	6 ~ 30	8	
*.asf	ASF	Divx 3.11 / 4.x / 5.1 / 6.0	1920x1080	6 ~ 30	8	MP3 / AC3 / LPCM / ADPCM / WMA
		XviD	1920x1080	6 ~ 30	8	
		H.264 BP / MP / HP	1920x1080	6 ~ 30	25	
		MPEG4 SP / ASP	1920x1080	6 ~ 30	8	
		Motion JPEG	800x600	6 ~ 30	8	
*.wmv	ASF	Window Media Video v9	1920x1080	6 ~ 30	25	WMA
*.mp4	MP4	H.264 BP / MP / HP	1920x1080	6 ~ 30	25	MP3 / ADPCM / AAC
		MPEG4 SP / ASP	1920x1080	6 ~ 30	8	
		XVID	1920x1080	6 ~ 30	8	
*.3gp	3GPP	H.264 BP / MP / HP	1920x1080	6 ~ 30	25	ADPCM / AAC / HE-AAC / QCELP / AMR NB/WB
		MPEG4 SP / ASP	1920x1080	6 ~ 30	8	
*.vro	VRO VOB	MPEG1	1920x1080	24 / 25 / 30	30	AC3 / MPEG / LPCM
		MPEG2	1920x1080	24 / 25 / 30	30	
*.mpg *.mpeg	PS	MPEG1	1920x1080	24 / 25 / 30	30	AC3 / MPEG / LPCM / AAC
		MPEG2	1920x1080	24 / 25 / 30	30	
		H.264	1920x1080	6 ~ 30	25	
*rmvb	RMVB	RV3.0/RV4.0	720x576	24/25/30	10	Real Audio 6,9,10(HE-AAC)
*.ts *.tp *.trp	TS	MPEG2	1920x1080	24 / 25 / 30	30	AC3 / AAC / MP3 / DD+ / HE-AAC
		H.264	1920x1080	6 ~ 30	25	
		VC1	1920x1080	6 ~ 30	25	

Other Restrictions

NOTE

- If there are problems with the contents of a codec, the codec will not be supported.
- If the information for a Container is incorrect and the file is in error, the Container will not be able to play correctly.
- Sound or video may not work if the contents have a standard bitrate/frame rate above the compatible Frame/sec listed in the table above.
- If the Index Table is in error, the Seek (Jump) function is not supported.

Video Decoder	Audio Decoder
• Supports up to H.264, Level 4.1 • H.264 FMO / ASO / RS, VC1 SP / MP / AP L4 and AVCHD are not supported. • XVID, MPEG4 SP, ASP: – Below 1280 x 720: 60 frame max – Above 1280 x 720: 30 frame max • GMC 2 over is not support. • Only Samsung Techwin MJEPG is supported.	• Supports up to WMA 7, 8, 9, STD • WMA 9 PRO does not support 2 channel excess multi channel or lossless audio. • WMA sampling rate 22050Hz mono is not supported.

Advanced Features

Playing movie continuously (Resume Play)

If you exit the playing movie function, the movie can be played later from the point where it was stopped.

1. Select the movie file you want to play continuously by pressing the ◄ or ► button to select it from the file list section.
2. Press the ► (Play)/ENTER button.
3. Select **Play Continuously** (Resume Play) by pressing the Blue button.

   ✎ The Movie will begin to play from where it was stopped.

   ✎ If the **Continuous Movie Play Help** function is set to **On** in the **Settings** menu, a pop-up message will appear when you resume play a movie file.

Music

Playing a Music

1. Press the ◄ or ► button to select **Music**, then press the ENTER button in the **Media Play** menu.
2. Press the ◄/►/▲/▼ button to select the desired **Music** in the file list.
3. Press the ENTER button or ► (Play) button.
   - During playing the music, you can search using the ◄ and ► button.
   - ◄◄ (REW) and ►► (FF) buttons do not function during play.

✎ Only displays the files with MP3 and PCM file extension. Other file extensions are not displayed, even if they are saved on the same USB device.



✎ If the sound is strange when playing MP3 files, adjust the Equalizer in the Sound menu. (An over-modulated MP3 file may cause a sound problem.)

Photos

Viewing a Photo (or Slide Show)

1. Press the ◄ or ► button to select **Photos**, then press the ENTER button in the **Media Play** menu.
2. Press the ◄/►/▲/▼ button to select the desired photo in the file list.
3. Press the ENTER button or ► (Play) button.
   - While a photo list is displayed, press the (Play)/ENTER button on the remote control to start slide show.
   - All files in the file list section will be displayed in the slide show.
   - During the slide show, files are displayed in order from currently being shown.

✎ Music files can be automatically played during the Slide Show if the **Background Music** is set to **On**.

Playing the multiple files

Playing the selected video/music/photo files

1. Press the Yellow button in the file list to select the desired file.
2. Repeat the above operation to select multiple files.

   NOTE

   - The (✓) mark appears to the left of the selected files.
   - To cancel a selection, press the Yellow button again.
   - To deselect all selected files, press the TOOLS button and select **Deselect All**.
3. Press the ▶(Play) / ENTER button.



Playing the video/music/photo file group

1. While a file list is displayed, move to the any file in desired group.
2. Press the TOOLS button and select **Play Current Group**.

Media Play Additional Function

Sorting the file list

Press the Blue button in the file list to sort the files.

Category	Operations	Videos	Music	Photos
Basic View	It shows whole folder. You can view the photo by selecting the folder.	✓	✓	✓
Title	It sorts and displays the file title in Symbol/Number/Alphabet/Special order.	✓	✓	✓
Preference	It sorts and displays the file by preference. You can change the file preference in the file list section using the Green button.	✓	✓	✓
Latest Date	It sorts and shows files by latest date.	✓		✓
Earliest Date	It sorts and shows files by earliest date.	✓		✓
Artist	It sorts the music file by artist in alphabetical.		✓	
Album	It sorts the music file by album in alphabetical order.		✓	
Genre	It sorts music files by the genre.		✓	
Mood	It sorts music files by the mood. You can change the music mood information.		✓	
Monthly	It sorts and shows photo files by month. It sorts only by month (from January to December) regardless of year.			✓

Videos/Music/Photos Play Option menu

During playing a file, press the TOOLS button.

Category	Operations	Videos	Music	Photos
Title	You can move the other file directly.	✓		
Repeat Mode	You can play movie or music files repeatedly.	✓	✓	
Picture Size (Mode1 / Mode2 / Original)	You can adjust the picture size for preference.	✓		
Lyric	You can play music with Lyric.		✓	
Picture Setting	You can adjust the picture setting (p. 12, 13, 14).	✓		✓
Sound Setting	You can adjust the sound setting (p. 14, 15).	✓	✓	✓
Subtitle Setting	You can play the video with Subtitle. This function only works if the subtitles are the same file type as the video.	✓		
Stop Slide Show / Start Slide Show	You can start or stop a Slide Show.			✓
Slide Show Speed	You can select the slide show speed during the slide show.			✓
Home Background	You can set Media Play home background.			✓
Background Music	You can set and select background music when watching a Slide Show.			✓
Zoom	You can zoom into images in full screen mode.			✓
Rotate	You can rotate images in full screen mode.			✓
Information	You can see detailed information about the played file.	✓	✓	✓

Settings

Using the Setup Menu

- **Background Settings**: Select to diplay the background you want.
- **Continuous Movie Play (Resume Play) Help (On / Off)**: Select to display the help pop-up message for continuous movie playback.
- **Get the DivX® VOD registration code**: Shows the registration code authorized for the TV. If you connect to the DivX web site and register the registration code with a personal account, you can download VOD registration file. If you play the VOD registration using Media Play, the registration is completed.

  ✎ For more information on DivX® VOD, visit www.DivX.com.
- **Get the DivX® VOD deactivation code**: When DivX® VOD is not registered, the registration deactivation code is displayed. If you execute this function when DivX® VOD is registered, the current DivX® VOD registration is deactivated.
- **Information**: Select to view information about the connected device.

Anynet+

What is Anynet+? TOOLS

Anynet+ is a function that enables you to control all connected Samsung devices that support Anynet+ with your Samsung TV's remote. The Anynet+ system can be used only with Samsung devices that have the Anynet+ feature. To be sure your Samsung device has this feature, check if there is an Anynet+ logo on it.

To connect to Home Theatre



1. Connect the **HDMI IN (1(DVI), 2, 3** or **4)** jack on the TV and the HDMI OUT jack of the corresponding Anynet+ device using an HDMI cable.
2. Connect the HDMI IN jack of the home theatre and the HDMI OUT jack of the corresponding Anynet+ device using an HDMI cable.

✎ **NOTE**

- Connect the Optical cable between the **DIGITAL AUDIO OUT (OPTICAL)** jack on your TV and the Digital Audio Input on the Home Theatre.
- When following the connection above, the Optical jack only outputs 2 channel audio. You will only hear sound from the Home Theatre's Front, Left and Right speakers and the subwoofer. If you want to hear 5.1 channel audio, connect the **DIGITAL AUDIO OUT (OPTICAL)** jack on the DVD / satellite box (i.e. Anynet Device 1 or 2) directly to the Amplifier or Home Theatre, not the TV.
- Connect only one Home Theatre.
- You can connect an Anynet+ device using the HDMI cable. Some HDMI cables may not support Anynet+ functions.
- Anynet+ works when the AV device supporting Anynet+ is in the standby or on status.
- Anynet+ supports up to 12 AV devices in total. Note that you can connect up to 3 devices of the same type.

Anynet+ Menu

The Anynet+ menu changes depending on the type and status of the Anynet+ devices connected to the TV.

Anynet+ Menu	Description
View TV	Changes Anynet+ mode to TV broadcast mode.
Device List	Shows the Anynet+ device list.
Recording: (*recorder)	Starts recording immediately using the recorder. (This is only available for devices that support the recording function.)
(device_name) **MENU**	Shows the connected device menus. E.g. If a DVD recorder is connected, the disc menu of the DVD recorder will appear.
(device_name) **INFO**	Shows the play menu of the connected device. E.g. If a DVD recorder is connected, the play menu of the DVD recorder will appear.
Stop Recording: (*recorder)	Stops recording.
Receiver	Sound is played through the receiver.

If more than one recording device is connected, they are displayed as (*recorder) and if only one recording device is connected, it will be represented as (*device_name).

Setting Up Anynet+

■ Setup

Anynet+ (HDMI-CEC) (Off / On): To use the Anynet+ Function, **Anynet+ (HDMI-CEC)** must be set to **On**.

✎ When the **Anynet+ (HDMI-CEC)** function is disabled, all the Anynet+ related operations are deactivated.

Auto Turn Off (No / Yes): Setting an Anynet+ Device to turn off automatically when the TV is turned off.

✎ The active source on the TV must be set to TV to use the Anynet+ function.

✎ Even if an external device is still recording, it may turn off.

Switching between Anynet+ Devices

1. Anynet+ devices connected to the TV are listed.

   ✎ If you cannot find a device you want, press the Red button to refresh the list.

2. Select a device and press the ENTER↵ button. You can switch to the selected device.

   ✎ Only when you set **Anynet+ (HDMI-CEC)** to **On** in the **Application** menu, the **Device List** menu appears.

   - Switching to the selected device may take up to 2 minutes. You cannot cancel the operation during the switching operation.
   - If you have selected external input mode by pressing the SOURCE button, you cannot use the Anynet+ function. Make sure to switch to an Anynet+ device by using the **Device List**.

Recording

You can make a recording of a TV programme using a Samsung recorder.

1. Select **Recording**.

   ✎ When there are more than two recording devices

   - When multiple recording devices are connected, the recording devices are listed. Select one recording device in the **Device List**.

   ✎ When the recording device is not displayed, select **Device List** and press the Red button to search devices.

2. Press the EXIT button to exit.

   ✎ You can record the source streams by selecting **Recording**: (device_name).

   ✎ Pressing the ● (REC) button will record whatever you are currently watching. If you are watching video from another device, the video from the device is recorded.

   ✎ Before recording, check whether the antenna jack is properly connected to the recording device. To properly connect an antenna to a recording device, refer to the recording device's users manual.

Listening through a Receiver

You can listen to sound through a receiver (i.e Home Theatre) instead of the TV speaker.

1. Select **Receiver** and set to **On**.
2. Press the **EXIT** button to exit.

✎ If your receiver supports audio only, it may not appear in the device list.

✎ The receiver will work when you have properly connected the optical in jack of the receiver to the **DIGITAL AUDIO OUT (OPTICAL)** jack of the TV.

✎ When the receiver (i.e Home Theatre) is set to On, you can hear sound output from the TV's Optical jack. When the TV is displaying a DTV (aerial) signal, the TV will send out 5.1 channel sound to the receiver. When the source is a digital component such as a DVD and is connected to the TV via HDMI, only 2 channel sound will be heard from the receiver.

✎ If there is a power interruption to the TV when the **Receiver** is set to **On** (by disconnecting the power cord or a power failure), the **Speaker Select** may be set to **External Speaker** when you turn the TV on again.

✎ **NOTE**

- You can only control Anynet+ devices using the TV remote control, not the buttons on the TV.
- The TV remote control may not work under certain conditions. If this occurs, reselect the Anynet+ device.
- The Anynet+ functions do not operate with other manufacturers' products.

Troubleshooting for Anynet+

Problem	Possible Solution
Anynet+ does not work.	• Check if the device is an Anynet+ device. The Anynet+ system supports Anynet+ devices only. • Connect only one receiver (home theatre). • Check if the Anynet+ device power cord is properly connected. • Check the Anynet+ device's Video/Audio/HDMI Cable connections. • Check whether Anynet+ (HDMI-CEC) is set to On in the Anynet+ setup menu. • Check whether it is Anynet+ exclusive remote control. • Anynet+ doesn't work in certain situations. (Searching channels, operating **Media Play** or **Plug & Play** (Initial setup), etc.) • When connecting or removing the HDMI cable, please make sure to search devices again or turn your TV off and on again. • Check if the Anynet+ Function of Anynet+ device is set on.
I want to start Anynet+.	• Check if the Anynet+ device is properly connected to the TV and check if the Anynet+ (HDMI-CEC) is set to On in the Anynet+ Setup menu. • Press the **TOOLS** button to display the Anynet+ menu and select a menu you want.
I want to exit Anynet+.	• Select **View TV** in the Anynet+ menu. • Press the **SOURCE** button on the TV remote control and select a device other than Anynet+ devices. • Press ⏻ ∨/∧, **PRE-CH**, and **FAV.CH** to change the TV mode. (Note that the channel button operates only when a tuner-embedded Anynet+ device is not connected.)
The message "Connecting to Anynet+ device..." appears on the screen.	• You cannot use the remote control when you are configuring Anynet+ or switching to a view mode. • Use the remote control when the Anynet+ setting or switching to view mode is complete.
The Anynet+ device does not play.	• You cannot use the play function when **Plug & Play** (Initial setup) is in progress.
The connected device is not displayed.	• Check whether or not the device supports Anynet+ functions. • Check whether or not the HDMI Cable is properly connected. • Check whether **Anynet+ (HDMI-CEC)** is set to **On** in the Anynet+ setup menu. • Search Anynet+ devices again. • You can connect an Anynet+ device using the HDMI Cable only. Some HDMI cables may not support Anynet+ functions. • If it is terminated by an abnormal situation such as disconnecting the HDMI cable or power cord or a power failure, please repeat the device scan.
The TV programme cannot be recorded.	• Check whether the antenna jack on the recording device is properly connected.
The TV sound is not output through the receiver.	• Connect the optical cable between TV and the receiver.

Getting Started with Internet@TV

Internet@TV brings useful and entertaining contents and services directly from the web to your TV.

✎ NOTE

- Configure the network settings before using **Internet@TV**. For more information, refer to “Network Connection”.
- Unsupported fonts within the provider’s content will not display normally.
- Slow responses and interruptions may occur, depending on your network conditions.
- English may be only supported in widget service depending on region.
- This feature is not available in all locations
- If you experience a problem using a widget, please contact the content provider.

Screen Display

TV Screen: Displays the current channel.

Information: Displays notices, new applications, and advertisemevnts brought to you by Samsung product introductions.

Application service: You can experience various service by provided samsung.

Recommended Applications: Displays the recommended service by Samsung. You are not able to add or delete a service in this list.

Downloaded Applications: Displays the downloaded applications through the Samsung Apps.

Internet@TV Settings: Edit and configure applications and **Internet@TV** settings.

Controls:

- A Red (**Login**): To log in to to **Internet@TV**.
- B Green (**Mark as Favourite**): To mark the Applications as a favourite.
- D Blue (**Sort by**): To sort the applications.
- ↩ **Return**: To return to the previous menu.

✎ The colour buttons may work differently depending on the application.

Account Login

For an application with multiple accounts, use ◄ and ► to access the different categories.

✎ For a more enjoyable widget experience, register and log in to your account.

✎ For instructions on creating an account, refer to **Setting** → **Internet@TV ID** → **Create**.

1. Press the Red button in **Internet@TV** home page.
2. Select desired **User account**, then press the ENTER↵ button.
   ✎ If you want create account, press Red button; then create account OSD window appear.
3. Enter the **Password**.
   ✎ When login succeeds, User account will be displayed on the screen.



Setting up Internet@TV

Settings

Create IDs and configure Internet@TV settings from this screen. Highlight Settings using ▲ and ▼ buttons and press the ENTER button.



■ **System Setup**

✎ **Ticker Autorun** may not be supported depending on country.

Ticker Autorun (Off / On): Enable/disable ticker autorun upon powering on the TV.

Channel Bound Service (Off / On): Some channels support application as an Internet data service, allowing you to access the Internet service while watching TV.

✎ Only available if supported by the broadcaster.

Reset: Resets Internet@TV settings to factory default settings.

Change the Service Lock password

✎ The default password set is "0-0-0-0."

✎ If you forget the password, press the following sequence of remote control buttons to reset the password to "0-0-0-0": POWER (off) → MUTE → 8 → 2 → 4 → POWER (on).

■ **Internet@TV ID**

You can use this menu when creating, deleting the account. You can control your account including contents site's account information.

✎ Account is only for internet@TV.

Create: Create an account and link it with desired service application.

✎ **NOTE**

- Account will be made less than 10.
- Maximum number of characters is 8.

Manager

– **Service Site**: Register login information for service sites.

– **Change Password**: Change account password.

– **Delete**: Delete the account.

■ **Service Manager**: Delete and lock application installed to Internet@TV.

Lock : Lock the application.

✎ Accessing a locked application. requires the password.

Delete : Delete the application

■ **Properties**: Display information about Internet@TV. Use the **Check the speed of your internet connection** option to test your network connection.

Using the Internet@TV service

Samsung Apps

Samsung Apps is a store for downloading applications to be used on Samsung TV/AV equipment.

Users can enjoy a variety of contents like videos, music, photos, games, useful information etc. using the downloaded applications.

Addi



✎ Using the colour buttons with the **Samsung Apps**.

- A Red (**Login**): To log in to the internet service.
- B Green (**Thumbnail View**): To change the view mode.
- D Blue (**Sort By**): To sort the applications by **Featured**, **Most downloaded**, **Most recent** or **Name**.
- **Return**: Moves to previous menu.

Using the Samsung Apps by category

The following categories are available:

- **What's New**: Displays newly registered applications.
- **Video**: Displays various video media such as movies, TV shows and short length videos.
- **Games**: Displays various games such as sudoku and chess.
- **Sports**: Displays various sports media such as match information, images and short length video.
- **Lifestyle**: Includes various lifestyle media services such as music, personal photo management tools and social networking such as Facebook and Twitter.
- **Information**: Includes various information services such as news, stocks and weather.
- **Others**: Includes other miscellaneous services.
- **My Page**: Displays the application list and your cyber cash balance.

  ✎ Starting in the middle of 2010 (US and Korea only), you can purchase cyber-cash for buying applications through tv.samsung.com.
- **Help**: If you have questions about Internet@TV, check this section first.

AllShare

About AllShare

AllShare connects your TV and mobile phones and other devices which are compatible with your TV through a network. On your TV, you can view call arrivals, SMS messages and schedules set on your mobile phones. In addition, you can play media contents including videos, photos and music saved on your mobile phones or the other devices (such as your PC) by controlling them on the TV via the network. Additionally, you can use your TV as a monitor for your mobile when browsing a web page.

✎ For more information, visit “www.samsung.com” or contact the Samsung call centre. Mobile devices may need additional software installation. For details, refer to each user’s guide.

Setting Up the AllShare

Setup

- **Message (On / Off)**: Enables or disables the message function (for call arrivals SMS messages and schedules set on your mobile phones).
- **Media (On / Off)**: Enables or disables the media function. When the media function is on, it plays videos, photos and music from a mobile phone or other device that supports AllShare.
- **ScreenShare (On / Off)**: Enables or disables ScreenShare accesses various contents from mobile phones or other ScreenShare supporting devices.
- **TV name**: Sets the TV name so you can find it easily on a mobile device.

  ✎ If you select **User Input**, you can type on the TV using the OSK (On Screen Keyboard).

Message / Media / ScreenShare

Shows a list of mobile phones or connected devices which have been set up with this TV for using the **Message, Media**, or **ScreenShare** function.

✎ The **Media** function is available in all mobile devices which support AllShare.

- **Allowed / Denied**: Allows/Blocks the mobile phone.
- **Delete**: Deletes the mobile phone from the list.

  ✎ This function only deletes the name of the mobile from the list. If the deleted mobile device is turned on or trieds to connect to the TV, it may appear on the list again.

Using the Message Function

Using this function, you view call arrivals, SMS messages and schedules set on the mobile phone through the alarm window while watching TV.

✎ **NOTE**

- To disable the alarm window, set **Message** to **Off** in **Setup** of **AllShare**.
- If OK is selected, or if OK is not selected after the message has appeared three times, the message will be deleted. The message is not deleted from the mobile phone.
- The alarm window can be displayed while using some applications such as **Media Play** etc. To view the contents of a message, switch to TV viewing mode.
- When a message from an unknown mobile phone is displayed, select the mobile phone on the message menu in **AllShare** and select **Denied** to block the phone.

Message View

If a new SMS message arrives while you are watching TV, the alarm window appears. If you click the OK button, the contents of the message are displayed.

✎ You can configure the viewing settings for SMS messages on your mobile phones. For the procedures, refer to the mobile phone manual.

✎ Some types of characters may be displayed as blank or broken characters.

Call Arrival Alarm

If a call arrives while you are watching TV, the alarm window appears.

Schedule Alarm

While you are watching TV, the alarm window appears to display the registered event.

✎ You can configure viewing settings for schedule contents on your mobile phones. For the procedures, refer to the mobile phone manual.

✎ Some special characters may be displayed as blank or broken characters.

Using the Media Function

An alarm window appears informing the user that the media contents (videos, photos, music) sent from a mobile phone will be displayed on your TV. The contents are played automatically 3 seconds after the alarm window appears. If you press the **RETURN** or **EXIT** button when the alarm window appears, the media contents are not played.

✎ **NOTE**

- To turn off the media contents transmission from the mobile phone, set **Media** to **Off** in the **AllShare** setup.
- Contents may not be played on your TV depending on their resolution and format.
- The **ENTER** and ◄ / ► buttons may not work depending on the type of media content.
- Using the mobile device, you can control the media playing. For details, refer to each mobile's user's guide.
- When you want to play media contents from your PC, select the PC icon on the main display of **AllShare**. Then the TV's **Media Play** menu automatically changes. For more detail information, refer to "Media Play".

Screenshare displays the same web page as provide in mobile. Using ScreenShare, you can open the various contents saved in a mobile phone. For example, the image below displays an access page for contents from a mobile. You can read the mobile's various files and view the phone book and calender on the TV. Also, in phone book, you can make a call to other person, or can send to SMS.

✎ **NOTE**

- In Samsung mobile, ScreenShare must be installed and the supporting application must be executed; then you can use the ScreenShare function.
- Available buttons on your remote control may vary for each page.
- **Doc Viewer** can read files in doc format, but cannot modify them.
- The screen display may differ depending on the connected device.

Using your Samsung phone to operatel your TV Simply

Before you can use this feature, you must connect to a Samsung mobile phone that supports ScreenShare functions. When operating the TV with your mobile phone, only the **POWER**, **– +**, **P ∧/∨** and **MUTE** buttons are supported.

✎ Even if you keep pressing down on a control button (channel or volume) on the mobile phone, the value will only go up or down by one unit.

Calendar

Menu -> Application -> Calendar -> ENTER

Calendar

Calendar function provides information such as solar calendar, lunar calendar, solar terms, heavenly stems, earthly branches, Chinese zodiac, western zodiac, holiday, etc. Among which, lunar calendar is used very often in our life. For example, all traditional Chinese festivals use lunar calendar, farming also needs to consult lunar calendar and solar terms, most Chinese people celebrate their birthdays according to lunar calendar, even when choosing big days such as wedding day, they would consult lunar calendar as well. Furthermore, the calendar is integrated with note function for you to edit important holiday information as a reminder.

Using the Message Function



A: focus date, the date you wish to check on.

B: Current date.

1 Red button: return to current system date.

2 / 3 Green/Yellow button: change month.

4 up/down/left/right button: move focus date up/down/left/right.

5 **Tools** button: provide the options to delete focus date note and to display note list.

6 **Enter** button: edit focus date note.

7 **Return**：return to up-level menu.

You can press the ▶▶ / ◀◀ button on the remote to change the year.

Edit note

You can use the note in calendar to input important holiday information as a reminder.



1.In **Calendar** menu, press up/down/left/right button to select the focus date.

2.Press **Enter** button to open the note editor, then select the appropriate input method to edit the note.

Tips

- Available input methods include PinYin (Simplified Chinese/Traditional Chinese), stroke (Simplified Chinese/ Traditional Chinese), English (capital/small letter), digits and other symbols.
- User can switch input method by using the "—" button on the remote and delete characters by using "**PRE-CH**" button.
- Key operation in abc/ABC input method:

– Press corresponding number key one or more times to enter candidate character

– Cursor disappears in the editor to indicate pending status until 1 second has past or another key has been pressed.

– The target character is selected when pending status ends.

3.After editing, press **Enter** button to save.

Tips

- If time information has been set, the focus date is current date. If time information hasn't be set, the focus date is default date (Jan 1, 2010).
- If notes have been added, the note for present day pops up when the TV is turned on.

– If there is no note, nothing pops up.

– The display time is 10 seconds.

– If there is channel information, it will pop up after the Channel Bar disappears. If there is no channel information, it will pop up after user handles the on-screen menu for searching channels.

– If the note is very long, it will display "..." at the end.

– The number of note entries must not exceed 100. (Otherwise, "The note list is full, please delete some notes before adding more" message appears.)

– There should be no more than 60 characters in each note.

Display/delete note

In **Calendar** menu, press **Tools** button to show note list, then delete any unwanted note.



Other Information

Installing the Wall Mount

Assembling the Blanking Bracket

When installing the TV onto a wall, attach the Blanking Bracket into the part that connects to the stand as shown in the picture.



Preparing before installing Wall-Mount (46 ~ 55 inch TVs)

To install a wall-mount from another manufacturer, use the Holder-Ring.



Installing the Wall Mount Kit

Wall mount items (sold separately) allow you to mount the TV on the wall.
For detailed information on installing the wall mount, see the instructions provided with the Wall Mount items. Contact a technician for assistance when installing the wall mount bracket.
Samsung Electronics is not responsible for any damage to the product or injury to yourself or others if you elect to install the TV on your own.

Wall Mount Kit Specifications (VESA)

✎ Wall mount kit is not supplied but sold separately.
Install your wall mount on a solid wall perpendicular to the floor. When attaching to other building materials, please contact your nearest dealer. If installed on a ceiling or slanted wall, it may fall and result in severe personal injury.

✎ NOTE

- Standard dimensions for wall mount kits are shown in the table below.
- When purchasing our wall mount kit, a detailed installation manual and all parts necessary for assembly are provided.
- Do not use screws longer than the standard dimension, as they may cause damage to the inside of the TV set.
- For wall mounts that do not comply with the VESA standard screw specifications, the length of the screws may differ depending on their specifications.
- Do not use screws that do not comply with the VESA standard screw specifications.
- Do not fasten the screws too strongly, this may damage the product or cause the product to fall, leading to personal injury. Samsung is not liable for these kinds of accidents.
- Samsung is not liable for product damage or personal injury when a non-VESA or non-specified wall mount is used or the consumer fails to follow the product installation instructions.
- Our 57” and 63” models do not comply with VESA Specifications. Therefore, you should use our dedicated wall mount kit for this model.
- Do not exceed 15 degrees tilt when mounting this TV.

Product Family	inches	VESA Spec. (A * B)	Standard Screw	Quantity
LCD-TV	19~22	75 X 75 100 X 100	M4	4
	23~29	200 X 100		
	30~40	200 X 200	M6	
	46~55	400 X 400	M8	
	57~65	600 X 400		
	70~80	800 X 400		
	80~	1400 X 800		



Do not install your Wall Mount Kit while your TV is turned on. It may result in personal injury due to electric shock.

Assembling the Cables

Enclose the cables in the Cable tie so that the cables are not visible through the transparent stand. Overly rigid or thick cables can damage input jacks for long term usage..



Anti-theft Kensington Lock

The Kensington Lock is not supplied by Samsung. It is a device used to physically fix the system when using it in a public place. The appearance and locking method may differ from the illustration depending on the manufacturer. Refer to the manual provided with the Kensington Lock for additional information on proper use.

✎ Please find a "" icon on the rear of the TV. A kensington slot is beside the "" icon.

1. Insert the locking device into the Kensington slot ❶ on the TV and turn it as shown ❷.
2. Connect the Kensington Lock cable ❸.
3. Fix the Kensington Lock to a desk or a heavy stationary object.

✎ The locking device has to be purchased separately.

✎ The location of the Kensington slot may be different depending on the TV model.



<Optional>

Securing the TV to the wall

Caution: Pulling, pushing, or climbing onto the TV may cause the TV to fall. In particular, ensure that your children do not hang over or destabilize the TV; doing so may cause the TV to tip over, resulting in serious injuries or death. Follow all safety precautions provided in the included Safety Flyer. For added stability and safety, install the anti-fall device as follows.

To Prevent the TV from Falling

✎ Since the necessary clamps, screws, and string are not supplied, please purchase these additionally.

1. Drive the screws into the clamps and firmly fasten them onto the wall. Make sure the screws are firmly fixed into the wall.
   ✎ Screw specifications
   - For a 30 ~ 40 Inch LCD TV: M6
   - For a 46 ~ 55 Inch LCD TV: M8
2. Remove the screws from the centre back of the TV, put the screws into the clamps, and then fasten the screws onto the TV again.
3. Connect the clamps fixed onto the TV and the clamps fixed onto the wall with a strong string and then tie the string tightly.





✎ Verify all connections are properly secured. Periodically check connections for any sign of fatigue or failure. If you have any doubt about the security of your connections, contact a professional installer.

✎ Install the TV near to the wall so that it does not fall backwards.

✎ When connecting the string, it is safest if the clamps on the wall are at an equal or lower height than the clamps on the TV.

✎ Untie the string before moving the TV.

Troubleshooting

If you have any questions about the TV, first refer to this list. If none of these troubleshooting tips apply, please visit "www.samsung.com," then click on Support, or contact the call centre listed on the back-cover of this manual.

Issues	Solutions and Explanations
Picture Quality	First of all, please perform the **Picture Test** and confirm that your TV is properly displaying test image. (go to MENU - **Support - Self Diagnosis - Picture Test**) If the test image is properly displayed, the poor picture may caused by the source or signal.
The TV image does not look as good as it did in the store.	• If you have an analogue cable/set top box, upgrade to a digital set top box. Use HDMI or Component cables to deliver HD (high definition) picture quality. • Cable/Satellite subscribers: Try HD stations from the channel line up. • Antenna connection: Try HD stations after performing Auto programme. ✎ Many HD channels are upscaled from SD(Standard Definition) contents. • Adjust the Cable/Set top box video output resolution to 1080i or 720p. • Make sure you are watching the TV at the minimum recommended distance based on the size and definition of the signal.
The picture is distorted: macroblock error, small block, dots, pixelization	• Compression of video contents may cause picture distortion especially in fast moving pictures such as sports and action movies. • Low signal level or bad quality can cause picture distortion. This is not a TV issue.
Colour is wrong or missing.	• If you're using a component connection, make sure the component cables are connected to the correct jacks. Incorrect or loose connections may cause colour problems or a blank screen.
There is poor colour or brightness.	• Adjust the **Picture** options in the TV menu. (go to **Picture** mode / **Colour / Brightness / Sharpness**) (p. 16) • Adjust **Energy Saving** option in the **TV** menu. (go to MENU - **Picture - ECO solution - Energy Saving**) • Try resetting the picture to view the default picture settings. (go to MENU - **Picture - Picture Reset**))
There is a dotted line on the edge of the screen.	• If the picture size is set to **Screen Fit**, change it to **16:9**. • Change cable/set top box resolution.
The picture is black and white.	• If you are using an AV composite input, connect the video cable (yellow) to the Green jack of component input 1 on the TV.
When changing channels, the picture freezes or is distorted or delayed.	• If connected with a cable box, please try to reset the cable box. Reconnect the AC cord and wait until the cable box reboots. It may take up to 20 minutes. • Set the output resolution of the cable box to 1080i or 720p.
Sound Quality	First of all, please perform the **Sound Test** to confirm that your TV audio is properly operating. (go to MENU - **Support - Self Diagnosis - Sound Test**) If the audio is OK, the sound problem may caused by the source or signal.
There is no sound or the sound is too low at maximum volume.	• Please check the volume the of external device connected to your TV.
The picture is good but there is no sound.	• Set the **Speaker Select** option to **TV speaker** in the sound menu. • If you are using an external device, make sure the audio cables are connected to the correct audio input jacks on the TV. • If you are using an external device, check the device's audio output option (ex. you may need to change your cable box's audio option to HDMI when you have a HDMI connected to your TV). • If you are using a DVI to HDMI cable, a separate audio cable is required. • If your TV has a headphone jack, make sure there is nothing plugged into it.
The speakers are making an inappropriate noise.	• Check the cable connections. Make sure a video cable is not connected to an audio input. • For antenna or cable connections, check the signal strength. Low signal level may cause sound distortion.
No Picture, No Video	
The TV won't turn on.	• Make sure the AC power cord is securely plugged in to the wall outlet and the TV. • Make sure the wall outlet is working. • Try pressing the POWER button on the TV to make sure the problem is not the remote. If the TV turns on, refer to "The remote control does not work" below.
The TV turns off automatically.	• Ensure the **Sleep Timer** is set to **Off** in the **Setup** menu. • If your PC is connected to the TV, check your PC power settings. • Make sure the AC power cord is plugged in securely to the wall outlet and the TV. • When watching TV from an antenna or cable connection, the TV will turn off after 10 ~ 15 minutes if there is no signal.

Other Information

Issues	Solutions and Explanations
There is no picture/Video.	• Check cable connections (remove and reconnect all cables connected to the TV and external devices). • Set your external devices' (Cable/Set top Box, DVD, Blu-ray etc) video outputs to match the connections to the TV input. For example, if an external device's output is HDMI, it should be connect to an HDMI input on the TV. • Make sure your connected devices are powered on. • Be sure to select the TV's correct source by pressing the SOURCE button on the TV remote.
RF(Cable/Antenna) Connection	
The TV is not receiving all channels.	• Make sure the Antenna cable is connected securely. • Please try **Plug & Play** (Initial setup) to add available channels to the channel list. Go to MENU - **Setup - Plug & Play** (Initial setup) and wait for all avaiable channels to be stored. • Verify the Antenna is positioned correctly.
The picture is distorted: macroblock error small block, dots, pixelization	• Compression of video contents may cause picture distortion, especially with fast moving pictures such as sports and action movies. • A low signal can cause picture distortion. This is not a TV issue.
PC Connection	
A "Not Supported Mode" message appears.	• Set your PC's output resolution and frequency so they matche the resolutions supported by the TV.
"PC" is always shown on the source list, even if a PC is not connected.	• This is normal; "PC" is always shown on the source list, regardless of whether a PC is connected.
The video is OK but there is no audio.	• If you are using a HDMI connection, check the audio output setting on your PC.
Network Connection (Depending on Models)	
Wireless network connection failed.	• Samsung Wireless USB dongle is required to use a wireless network. • Make sure the Network Connection is set to Wireless. • Make sure the TV is be connected to a wireless IP sharer (router).
Others	
The picture won't display in full screen.	• HD channels will have black bars on either side of the screen when displaying upscaled SD (4:3) contents. • Black bars on the top and bottom will appear during movies that have aspect ratios different from your TV. • Adjust the picture size options on your external device or TV to full screen.
The remote control does not work.	• Replace the remote control batteries with the poles (+/–) in the right direction. • Clean the sensor's transmission window on the remote. • Try pointing the remote directly at the TV from 5~6 feet away.
The cable/set top box remote control doesn't turn the TV on or off, or adjust the volume.	• Programme the Cable/Set top box remote control to operate the TV. Refer to the Cable/Set user manual for the SAMSUNG TV code.
A "Not Supported Mode" message appears.	• Check the supported resolution of the TV, and adjust the external device's output resolution accordingly. Refer to the resolution settings on page 24 of this manual.
There is a plastic smell from the TV.	• This smell is normal and will dissipate over time.
The TV **Signal Information** is unavailable in the Self Diagnostic Test menu.	• This function is only available with digital channels from an Antenna / RF/Coax connection.
The TV is tilted to the side.	• Remove the base stand from the TV and reassemble it.
There are difficulties assembling the stand base.	• Make sure the TV is placed on a flat surface. If you can not remove the screws from the TV, use a magnetized screw driver.
The channel menu is greyed out. (unavailable)	• The **Channel** menu is only available when the TV source is selected.
Your settings are lost after 30 minutes or every time the TV is turned off.	• If the TV is in the **Store Demo** mode, it will reset picture settings every 30 minutes. Change the settings from **Store Demo** mode to **Home Use** mode in the **Plug & Play** (Initial setup) procedure. Press the SOURCE button to select **TV** mode, and go to MENU → **Setup** → **Plug & Play** (Initial setup) → ENTER↵.
You have intermittent loss of audio or video.	• Check the cable connections and reconnect them. • Loss of audio or video can be caused by using overly rigid or thick cables. Make sure the cables are flexible enough for long term use. If mounting the TV to the wall, we recommend using cables with 90 degree connectors.

Issues	Solutions and Explanations
You see small particles when you look closely at the edge of the frame of the TV.	• This is part of the product's design and is not a defect.
The **PIP** menu is not available.	• **PIP** functionality is only available when you are using a HDMI, PC or components source.
The message "Scramble signal" or "Weak Signal/No Signal" appears.	• If you are using a CAM CARD (CI/CI+), check that it is installed into the common interface slot. • If there is still a problem, pull the CAM CARD out of the TV and insert it into the slot again.
You turned the TV off 45 minutes ago, and it turned on again.	• It is normal. The TV operates the OTA (Over The Aerial) function itself to upgrade software downloaded whilst your watching TV.
There are recurrent picture/sound issues.	• Check and change the signal/source.
A reaction may occur between the rubber cushion pads on the base stand and the top finish of some furniture.	• To prevent this, use felt pads on any surface of the TV that comes in direct contact with furniture.

✎ This TFT LCD panel uses a panel consisting of sub pixels which require sophisticated technology to produce. However, there may be a few bright or dark pixels on the screen. These pixels will have no impact on the performance of the product.

Licence

SRS TheaterSound

TheaterSound, SRS and the symbol are trademarks of SRS Labs, Inc.
TheaterSound technology is incorporated under license form SRS Lab, Inc.

DOLBY DIGITAL PLUS PULSE

Manufactured under licence from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

dts 2.0+Digital Out

Manufactured under license under U.S. Patent #'s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS and the Symbol are registered trademarks. & DTS 2.0+ Digital Out and the DTS logos are trademarks of DTS, Inc. Product Includes software. © DTS, Inc. All Rights Reserved.

DIVX

DivX® is certified to play DivX® video, including premium content.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX,Inc. This is an official DivX Certified device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX video.
ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX VOD.

Other Information

Specifications			
Model Name	**LA32C650**	**LA37C650**	**LA40C650**
Screen Size (Diagonal)	32 inch	37 inch	40 inch
PC Resolution (Optimum)	1920 X 1080 @ 60 Hz	1920 X 1080 @ 60 Hz	1920 X 1080 @ 60 Hz
Sound Output	10W x 2	10W x 2	10W x 2
Dimension (WxDxH) Without Stand With Stand	789.2 X 77.8 X 509.9 mm 789.2 X 240 X 555.9 mm	907.6 X 78.5 X 574.4 mm 907.6 X 255 X 621.2 mm	976.2 X 80.4 X 614.9 mm 976.2 X 255 X 659.3 mm
Weight With Stand	11.8 kg	15 kg	17.7 kg
Environmental Considerations Operating Temperature Operating Humidity Storage Temperature Storage Humidity	10°C to 40°C (50°F to 104°F) 10% to 80%, non-condensing -20°C to 45°C (-4°F to 113°F) 5% to 95%, non-condensing		
Stand Swivel (Left / Right)	-20˚ ~ 20˚		

Model Name	**LA46C650**	**LA40C630**	**LA46C630**
Screen Size (Diagonal)	46 inch	40 inch	46 inch
PC Resolution (Optimum)	1920 X 1080 @ 60 Hz	1920 X 1080 @ 60 Hz	1920 X 1080 @ 60 Hz
Sound Output	15W x 2	10W x 2	10W x 2
Dimension (WxDxH) Without Stand With Stand	1108.6 X 80.3 X 689.7 mm 1108.6 X 275 X 734.5 mm	977.8 X 80.3 X 595.0 mm 977.8 X 255.0 X 660.1 mm	1110.2 X 80.3 X 670.5 mm 1110.2 X 275.0 X 735.3 mm
Weight With Stand	21.9 kg	17.6kg	21.8kg
Environmental Considerations Operating Temperature Operating Humidity Storage Temperature Storage Humidity	10°C to 40°C (50°F to 104°F) 10% to 80%, non-condensing -20°C to 45°C (-4°F to 113°F) 5% to 95%, non-condensing		
Stand Swivel (Left / Right)	-20˚ ~ 20˚		

✎ Design and specifications are subject to change without prior notice.

✎ For information about power supply, and more about power consumption, refer to the label attached to the product.

This page is intentionally left blank.